mecc alte

Totally Focused. Totally Independent.

EN

User Manual

Self-regulating Alternators

ECO 43
ECO 46

Operating and maintenance instructions

Code: Series ECO
Revision: 7
Data: 03/26

Translation of original language

CE

The world's largest independent producer of alternators 1 – 5,000kVA

Index

Contenuti

1 General information: purpose of the manual 6
1.1 Intended Users 6
1.2 Professional Profiles Involved 6
1.3 Manual use and storage 7
1.4 How to consult the manual 8
1.4.1 Description of the symbols/pictographs in the manual 8
1.5 Reference Regulations and Directives 9
1.6 Marking data 10
1.7 Declaration of Conformity 11
1.8 Support 13
1.9 Glossary 13
2 Presentation of the alternator 14
2.1 Main components 14
2.1.1 DSR digital regulator 15
2.1.2 DER1 digital regulator 15
2.2 General description and principle of operation 16
2.3 Technical Data 17
2.3.1 Dynamic Data Support (DDS) 17
2.3.2 Radial Loads 18
2.3.3 Alignment tolerances in B3B14 18
2.3.4 Materials 18
2.4 Environmental operating conditions 18
3 Safety 19
3.1 General warnings 19
3.2 Alternator safety devices 20
3.3 Safety tags 20
3.4 Personal Protective Equipment 21
3.5 Residual risks 21
4 Transport, handling and storage 22
4.1 General warnings 22
4.2 Packing materials lifting and transportation 23
4.3 Unpacking 23
4.4 How to dispose of the packing materials 23
4.5 Alternator Movement 24

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

4.6 Storage 24
5 Installation instructions / coupling with driving engine 25
5.1 Installation Setup 25
5.2 Mechanical coupling 26
5.2.1 Alternator Preparation 27
5.2.2 Aligning the drive motor to the B3B14 alternator 27
5.2.3 Alignment of the driving engine with the alternator in MD35 27
5.2.4 Compensation for thermal expansion 28
6 Electrical connection 29
6.1 Terminal board configurations 32
6.1.1 ECO 43 regulation box and cable connection 32
6.1.2 ECO 46 regulation box and cable connection 33
6.2 Parallel connection of alternators 34
6.2.1 Installation of a parallel device 34
7 Initial start-up instructions 35
8 Electronic regulators 36
8.1 DSR digital regulator 36
8.1.1 Stability setting 37
8.1.2 Protections 37
8.1.3 Inputs and outputs: technical specifications 38
8.2 DER1 digital regulator 41
8.2.1 Stability setting 42
8.2.2 Protections 42
8.2.3 Inputs and outputs: technical specifications 43
8.3 UVR6-SR7 analog regulators 47
8.4 M2K / M3K digital regulator 49
9 Maintenance 50
9.1 General warnings 50
9.2 Maintenance summary table 51
9.2.1 Ordinary maintenance summary table 51
9.2.2 Extraordinary maintenance summary table 51
9.2.3 Summary table of maintenance operations in case of failure 52
9.3 Routine maintenance 53
9.3.1 General Cleaning 53
9.3.2 Air filter cleaning (if present) 54
9.3.3 Visual Inspection 55
9.3.4 Verification of winding state 55

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.3.5 Verification of correct alternator operation 56
9.3.6 Tightening torque check 56
9.3.7 External and internal cleaning of the alternator 57
9.4 Extraordinary maintenance 58
9.4.1 Maintenance of bearings and possible replacement 58
9.4.2 Winding state and diode bridge fastening check 59
9.4.3 Copy of the alarms of the digital regulator 59
9.4.4 Check correct fastening of PMG (optional component) 60
9.4.5 Cleaning of windings 61
9.5 Maintenance in case of failure 62
9.5.1 Fan replacement assembling 62
9.5.2 Check and possible replacement of diode bridge 63
9.5.3 Mechanical disassembly for inspection (series 43-46) 64
9.5.3.1 Note for removal of ECO 43 - 46 alternators 69
9.5.4 Mechanical assembly (series 43 - 46) 70
9.5.5 PMG disassembling 73
9.5.6 PMG assembly (series 43–46) 74
9.5.7 Removal of disc holder hub 76
9.5.8 Loss of residual magnetism (re-excitation of the machine) 77
9.5.9 Check and replacement of voltage regulator 78
9.5.10 DSR test and setup on test bench 81
9.5.11 DER1 test and setup on test bench 83
9.5.12 DER 2 test and setup on test bench 85
9.5.13 Main stator windings voltage test 87
9.5.13.1 Resistance/Continuity Test 88
9.5.13.2 Insulation test 89
9.6 General tightening torques 90
9.6.1 ECO43 Series 90
9.6.2 ECO46 Series 92
9.7 Disc tightening torques 94
9.8 Terminal block tightening torques 94
10 Alarm management DSR / DER1 95
10.1 DSR/DER1 digital regulator alarms 96
11 Problems, causes and remedies 98
12 Wiring diagrams 100
12.1 DSR digital regulator wiring diagrams 101
12.2 DER 1 digital regulator electrical diagrams 104

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

12.3 Wiring diagrams with PMG 112
12.4 Electrical diagrams with UVR6 - SR7 regulators 117
13 Spare parts 125
13.1 ECO 43A Construction type MD35 126
13.2 ECO 43A Construction type B3B14 128
13.3 ECO 46A Construction type MD35 130
13.4 ECO 46A Construction type B3B14 132
14 Disassembly and disposal 134

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

1 General information: purpose of the manual

This manual is intended to provide support and guidance during the stages of work on the alternator. It contains information on the use, maintenance and handling of faults and malfunctions providing indications for the most adequate behavior to the correct use and to the correct operation of the machine as specified by the Manufacturer. This manual is an essential safety requirement and it must accompany the alternator throughout its life cycle. It is indispensable to store this manual and to make it available to everyone involved in using and servicing the alternator.

This document and/or its parts may not be reproduced or disclosed to third parties without the prior consent of MECC ALTE S.p.A.

MECC ALTE S.p.A. is not responsible or liable for any damages suffered by people or things as a result of improper use not indicated in this manual and by failure to comply with the specifications of the technical characteristics table pertaining to every model.

1.1 Intended Users

This manual is intended for the authorized personnel adequately trained to operate this kind of product.

Warning

The operators must not carry out operations reserved to maintenance technicians or to specialized technicians. The Manufacturer disclaims all responsibility for damages suffered as a result of failure to comply with this warning.

1.2 Professional Profiles Involved

Below we describe the professional profiles who may operate the alternator based on the kind of activity to be carried out.

Handler

Authorized skilled personnel able to safely lift and handle the alternator. The operator is not authorized to carry out maintenance operations.

Mechanical Maintenance Technician

A qualified technician able to carry out the installation, adjustment, maintenance and ordinary repair operations required. Not allowed to carry out operations with the power on.

Electrical Maintenance Operator

A qualified technician in charge with all the electrical works of connection, adjustment, maintenance and repair. Authorized to carry out operations with the power on.

Field Service Technician

A qualified technician provided by the manufacturer to carry out complex operations in special cases or, anyway, as previously agreed with the user.

1.3 Manual use and storage

Warning

Read this manual carefully before starting up the alternator or carrying out any operation on it. If you do not read it you might not be able to recognize potential hazardous situations that may lead to death or serious injuries inflicted to yourself or to others.

This manual is intended to provide all the information required for a correct use of the alternator and its most autonomous and safest possible management.
It is mandatory for all the users and the maintenance technicians to carefully read the instructions contained in this manual and in all possible annexes, before carrying out any operation on the product.
In case of doubts on the correct interpretation of the information reported in the documentation, please contact the manufacturer for clarifications.

Caution

Keep this manual and all its annexes in good condition, legible and complete in all its parts. Keep the documentation close to your alternator, in an accessible place known to all the operators and maintenance technicians and, more generally, to everyone who for various reasons should operate the alternator.

Warning

Keep the manual in its original condition. It is forbidden to rewrite, change or remove pages from the manual and their contents. The manufacturer disclaims all responsibility for any potential damages to people, animals or things as a result of failure to comply with the instructions and with the operational modalities described in this manual.

This manual is an integral part of the alternator and it must be stored for future reference.

Caution

This manual must be delivered together with the alternator in case the alternator is transferred/sold to another user.

Caution

In case the manual is lost or damaged ask for a copy from the Manufacturer indicating its identification data: document name, code, revision number and issue date.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

1.4 How to consult the manual

- The manual is divided in chapters, paragraphs and subparagraphs listed in the table of contents: an easy way to find any topic of interest.
- The symbols used provide direct knowledge on the kind of information expressed by each symbol. For instance the symbol:


This symbol indicates a NOTE.

1.4.1 Description of the symbols/pictographs in the manual

Below you will find the various symbols used in the manual to highlight information of particular importance or the intended recipients of the specific pieces of information.


Danger
The risks described in this manner indicate a HIGH LEVEL of hazard that, unless avoided, could cause severe injuries or death.


Warning
The risks described in this manner indicate an INTERMEDIATE LEVEL of hazard that, unless avoided, could cause severe injuries or death.

Caution
The risks described in this manner indicate a LOW LEVEL of hazard that, unless avoided, could cause minor or moderate injuries.


This symbol indicates a NOTE; a fundamentally important piece of information or in-depth explanation.


This symbol indicates a CROSS REFERENCE; the presence of a module, of a drawing or of an annexed document that should be consulted and, if required, filled in.

1.5 Reference Regulations and Directives

List of the reference regulations and directives used for the design and construction of the alternator.
Directives

- Machinery Directive 2006/42/EC.
- Low Voltage Directive 2014/35/EC.
- EMC Directive 2014/30/EC.

Applicable Harmonized Technical Standards

- EN ISO 12100 (2010) : Safety of machinery – General principles of design – Risk assessment and risk reduction
- EN 60034-1 : Rotating Electrical Machines - Part 1 : Rating and performance.
- EN 60204-1: Safety of machinery. Electrical equipment of machines. Part 1: General Requirements
- EN61000-6-3 : Electromagnetic Compatibility (EMC) Part 6-3: Generic Standards - Emission standard for Residential, Commercial and Light-industrial Environments.
- EN61000-6-2 : Electromagnetic Compatibility (EMC) Part 6-2: Generic Standards - Immunity for industrial environments

Applicable Technical Standards

- EN 60034-2 : Method for determining losses and efficiency
- EN 60034-5 : Classification of degrees of protection (IP).
- EN 60034-6 : Methods of cooling (IC)
- EN 60034-7 : Types of construction (IM code)
- EN 60034-8 : Terminal markings and direction of rotation
- EN 60034-9 : Noise limits
- EN 60034-14 : Mechanical vibration limits
- EN 60085 : Classification of insulating materials
- ISO 1940-1 : Balance quality requirements of rigid rotors


Technical standards to be applied by the installer

- ISO 8528-9 : Reciprocating internal combustion engine driven alternating current generating sets Part 9: Measurement and evaluation of mechanical vibrations.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

1.6 Marking data

Alternator Nameplate




1. Serial number
2. Model
3. Revision index
4. Phase number
5. Service type
6. Manufacture month / year
7. Nominal speed
8. Insulation class
9. Power factor
10. Nominal power related to temperature (11)
11. Maximum ambient temperature
12. Nominal Voltage
13. Nominal Current
14. Nominal Frequency
15. Nominal characteristics class
16. Connection type
17. Excitation Voltage
18. Excitation Current
19. Power related to temperature (20)
20. Ambient temperature
21. Nominal Voltage
22. Current related to power (19)
23. Nominal Frequency
24. Protection Rating
25. Total weight
26. Moment of inertia
27. Bearing type

Ask for a new nameplate if the one attached to the alternator cannot be read anymore.

The nameplate is affixed on the alternator in the position indicated in the figure.

1.7 Declaration of Conformity

Below a copy of the declaration of conformity of the product. The original is placed inside the terminal box of every alternator. A true copy may be requested in case of loss.



mecc alte
www.meccalte.com

CONFORMITY DECLARATION

DICHIARAZIONE DI CONFORMITÀ | DECLARATION DE CONFORMITÉ
KONFORMITÄTS ERKLÄRUNG | DECLARACION DE CONFORMIDAD

Mecc Alte declares under its sole responsibility that the machine	Mecc Alte dichiara sotto la propria esclusiva responsabilità che la macchina	Mecc Alte déclare sous sa seule responsabilité que la machine	Mecc Alte erklärt in alleiniger Verantwortung, dass die Maschine	Mecc Alte declara bajo su exclusiva responsabilidad que la máquina
as described in the attached documents, files, is in conformity with	così come descritta nei documenti allegati, fascicoli, è conforme a	telle que décrite dans les documents, fichiers joints est conforme à	wie in den beigefügten Dokumenten, Dateien beschrieben konform ist mit	tal como se describe en los documentos adjuntos, archiva es conforme con

2006/42/EC, 2014/35/EU, 2014/30/EU, 2011/ 2015/ 63, EN ISO 12100, EN 60204-1, EN IEC 61000-6-2, EN IEC 000-6 EN 6 34-1

BS EN ISO 12100, BS EN 60204- EN IE 61000-6-2, BS EN IEC 61000-6-3, BS EN 60034-1, Electromagnetic Compati ty Regulations 2016, Electrical Equipment (Safety) Regulations 2016, Supply of Machinery (Safety) Regulations 2016

This machine must not be put into service until the machine in which it is intended to be incorporated into, has been declared to be in conformity with the provisions of 2006/42/CEE Machinery Directive.	Questa macchina non deve essere in servizio fino a quando la macchina in cui è destinata ad essere incorporata, non sia stata dichiarata conforme alle disposizioni della Direttiva Macchine 2006/42/CEE.	Cette machine ne doit pas être mise en service tant que la machine dans laquelle elle est destinée à être intégrée a pas été déclarée conforme aux dispositions de la Directive Machines 2006/42/CEE.	Diese Maschine darf nicht in Betrieb genommen werden, bis die Maschine, in die sie eingebaut werden soll, für konform mit den Bestimmungen der Maschinenrichtlinie 2006/42/EWG erklärt wurde.	Esta máquina no debe ponerse en servicio hasta que la máquina en la que se pretende incorporar haya sido declarada conforme a las disposiciones de la Directiva de Máquinas 2006/42/CEE.
This declaration is in conformity with the general criteria indicated by EN1 European Standard.	Questa dichiarazione è conforme ai criteri generali indicati dalla norma europea EN17050.	Cette déclaration est conforme aux critères généraux indiqués par la norme européenne EN17050.	Diese Erklärung entspricht den allgemeinen Kriterien der europäischen Norm EN17050.	Esta declaración está en conformidad con los criterios generales indicados por la Norma Europea EN17050.
This machine was produced in:	Questa macchina è stata prodotta a:	Cette machine a été produite en:	Diese Maschine wurde produziert:	Esta máquina se produjo en:

MECC ALTE
via ROMA 20, 36051
Creazzo, Vicenza
ITALY
P.IVA 01267440244
TEL +39 0444 396111
FAX +39 0444 396166
info@meccalte.it

MECC ALTE UK LTD
6 LAND'S END WAY
Oakham Rutland
UK
VAT GB 690 7302 32
TEL +44 01572 771160
FAX +44 01572 771161
info@meccalte.co.uk

MECC ALTE ALTERNATOR
(NANTONG) Ltd
755, NANHAI EAST ROAD
JIANGSU NANTONG HEDZ 226100
PRC
VAT 320684785587760
TEL (86) 513-82325758
FAX (86) 513-82325768
info@meccalte.cn

MECC ALTE INDIA PVT LTD
PLOT No 1
TELAGON DHAMDHERE S.O.
TALUKA: SHIRUR,
DISTRICT: PUNE 412208
MAHARASHTRA, INDIA
TEL. +91 2137 673200
FAX +91 2137 673299
info@meccalte.in

Position | Posizione | Position | Stelle | Posición
First name and surname | Nome e cognome | Nom et prenom | Vor-und Nachname | Nombre y apellido
Signature | Firma | Signature | Unterschrift | Firma

L'Amministratore Delegato
MARIO ROBERTO CARRARO

Mod. CE-UKCA - IT | rev.00

1/2

FAC-SIMILE

RESIDUAL RISKS LIST

The manufacturer MECC ALTE took all possible precautions to construct the generator following all safety regulations and present applicable Safety Norms.
The instruction manual explains step by step all indications required in point 1.7.4 (user instructions) of the Machines Directive and all users are specifically asked to read it carefully in order to avoid wrong operations which, even though simple, could cause damage to persons. If all instructions given are followed, no residual risks are left; however, one has to pay attention to the warnings given :

1) move carefully the generator (packed and unpacked)
2) the coupling of the generator with the drive-machine and the electrical connections should be performed by skilled personnel
3) do not touch the generator during function and immediately after being stopped since some parts of the generator could be hot
4) in case of generator with permanent magnets, take proper precautions and keep appropriate distance.

LISTA RISCHI RESIDUI

La MECC ALTE ha fatto tutto il possibile per fabbricare il generatore con il massimo della conoscenza sulle sicurezze al Suo possesso e consultando tutte le Direttive e Norme attualmente applicabili.
Il manuale d'uso ed istruzione riporta passo-passo tutte le indicazioni richieste dal punto 1.7.4 (istruzioni d'uso) della Direttiva Macchine ed è fatta specifica richiesta di leggerlo attentamente cosi' da non incorrere in operazioni errate che, se pur minime, possono causare danni alle persone.
Se vengono rispettate tutte le indicazioni fornite, non rimangono particolari rischi residui, ma solamente delle attenzioni che sono

1) movimentare il generatore con accortezza (imballato e disimballato)
2) far accoppiare il generatore alla macchina di trascinamento e far collegare elettricamente lo stesso, da personale adeguatamente istruito
3) non toccare il generatore durante il funzionamento e subito dopo l'arresto dello stesso, in quanto vi potrebbero essere parti del generatore a temperature elevate
4) se il generatore presenta magneti permanenti all'interno, prendere le dovute precauzioni e mantenere le giuste distanze.

LISTE DES RISQUES RÉSIDUELS

La société Mecc Alte a pris toutes ses précautions pour fabriquer les alternateurs avec le maximum de sécurité à sa connaissance, et en consultant toutes les directives et normes actuellement applicables.
Le manuel d'utilisation et d'instruction explique point par point toutes les indications requises au point 1.7.4 (instruction d'utilisation) de la Directive des Machines, et tous les utilisateurs sont spécifiquement sollicités à lire avec attention afin d'éviter toutes fausses opérations qui, même minimes, peuvent être dangereuses pour l'utilisateur. Si toutes les instructions données sont suivies, il n'y a aucun risque résiduel particulier, mais seulement quelques précautions à prendre qui sont :

1) manipuler l'alternateur avec prudence (emballage et désemballage)
2) effectuer l'accouplement entre l'alternateur avec le système d'entraînement et les connections électriques par du personnel qualifié
3) ne pas toucher l'alternateur durant son fonctionnement et aussitôt après son arrêt, car certaines pièces peuvent encore être à température élevée
4) Dans le cas d'un générateur à aimants permanents, prendre les précautions appropriées et garder une distance appropriée.

LISTE DER NACHBLEIBENDEN GEFAHREN

Der Hersteller MECC ALTE hat alle möglichen Vorsichtsmaßnahmen bei der Herstellung des Generators nach geltenden Sicherheitsvorschriften und den z.Zt. anwendbaren Sicherheitsnormen eingehalten.
Die Bedienungsanleitung erklärt schrittweise alle Indikatoren die in Pkt.1.7.4 (Gebrauchsanweisung) der Maschinenbauvorschrift gefragt sind. Alle Anwender werden dringend gebeten, diese Hinweise zu lesen, um auch den kleinsten Fehler zu vermeiden, der Personenschaden verursachen könnte. Bei genauer Beachtung der Vorschriften verbleibt kein Risiko; jedoch müssen die folgenden Warnungen beachtet werden :

1) den Generator (verpackt und unverpackt) vorsichtig transportieren
2) die Kopplung des Generators mit der Antriebsmaschine und die elektrischen Verbindungen nur durch qualifiziertes Personal ausführen lassen
3) den Generator während des Betriebs und kurz nach dem Abstellen nicht berühren, da Teile des Generators heiß sein können
4) Bei Generatoren mit Dauermagneten sind entsprechende Vorsichtsmaßnahmen zu treffen und ein angemessener Abstand einzuhalten.

LISTA DE LOS RIESGOS RESIDUALES

La MECC ALTE ha hecho todo el posible para fabricar el generador con los máximos conocimientos sobre seguridad en su poder, y consultando todas las directivas y normas actualmente aplicables.
El manual de uso e instrucciones explica paso a paso todas las indicaciones requeridas por el punto 1.7.4 (instrucciones de uso) de la Directiva Máquinas, y hace una particular solicitud de leer atentamente el mismo, de manera de evitar operaciones erradas, que si bien mínimas, podrían provocar daños a las personas. Si son respetadas todas las indicaciones dadas, prácticamente no quedan riesgos residuales, a parte los siguientes puntos:

1) manipular el generador con cuidado (embalado y desembalado)
2) acoplar el generador con la máquina que da el movimiento primario, y conectar eléctricamente el mismo, por personal adecuadamente calificado
3) no tocar el generador durante el funcionamiento, así como, inmediatamente después que el mismo se detiene, debido a que podrían existir partes del generador a altas temperaturas
4) en caso de generador con imanes permanentes, tome las debidas precauciones y mantenga la distancia apropiada.

FAC-SIMILE

1.8 Support

For any inquiry on the use, the maintenance or a request of replacement parts, the buyer must contact the Manufacturer directly (or the help desk if present), specifying the alternator identification data indicated on the nameplate.
The Customer may resort to the technical and commercial support provided by the area representatives or by foreign branches, which are in direct contact with MECC ALTE S.p.A. and have their addresses and contact data indicated on the back cover.
In case of fault or an insurmountable inconvenience, the Customer may contact directly the headquarters using the following data:

PHONE NUMBER (Landline):	+ 39 0444 396111
E-MAIL:	aftersales@meccalte.it
WEBSITE:	www.meccalte.com
MAILING ADDRESS:	MECC ALTE S.p.A Via Roma 36051 Creazzo, Vicenza Italy

In case of ownership transfer or company transfers of the alternator you should always inform the manufacturing company or your reference help desk.


1.9 Glossary

System:	System means, in brief, the drive motor and the alternator.
Installer:	A person / company that is in charge of building the "Fully assembled Machine" and/or installing it at the user's premises.
Fully Assembled Machine:	It is the name of the complete machine mainly made up of a "drive motor" and the alternator.
Drive motor:	It is the motor to which the alternator is connected. The manual also defines it as the "drive machine".
PPE:	Personal Protective Equipment.

2 Presentation of the alternator


ECO Series alternators are self-regulated, 4-pole brushless alternators.
They are equipped with a rotating inductor (1) fitted with a damper cage and stationary armature with inclined grooves.
The winding is short pitched so as to reduce the harmonics.
The electromagnetic compatibility tests were carried out in compliance with the standard specifications, with the neutral wire connected to ground.
Testing in accordance with other specifications may be carried out on request of the customer.
The mechanical structure, always very robust, allows easy access to the connections and inspections of the various components.
The case is made of steel, the shields are made of cast iron, the shaft is made of C45 steel with a fan splined onto the shaft.
The protection rating is IP23 (higher protection ratings can be achieved on request).
Insulation if of class H standard.
The impregnations are realized with polyester resin for the rotating parts and with vacuum treatment for the parts that have higher voltage such as for instance the stators.
Special treatments may also be carried out on request.

2.1 Main components



1. Rotating Inductor
2. Cooling fan
3. Main rotor
4. Exciter Rotor
5. Terminal Box
6. Stator Frame
7. Mounting Feet
8. Protection Grid
9. Front Cover
10. Shaft
11. PMG


2.1.1 DSR digital regulator



dis_ECO_022-r00

The electronic regulators may be of 2 types: DSR, DSR/A.
DSR/A can be mounted on the 43-46 series on customer request.
The regulator is normally installed in the terminal box of the alternator.


2.1.2 DER1 digital regulator



dis_ECO_023-r00

The electronic regulators may be of 2 types: DER1, DER1/A.
Standard supply comes with the DER1 on the 43-46 series.
The regulator is normally installed in the terminal box of the alternator.

2.1.3 Digital regulator M2K



Upon customer request, the M2K/M2Ks digital regulator can be supplied on the series.
The regulator is normally installed in the terminal box of the alternator.


2.1.4 Digital regulator M3K



Upon customer request, the M3K/M3Ks/M3KsHD digital regulator can be supplied on the series.
The regulator is normally installed in the terminal box of the alternator.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

2.2 General description and principle of operation



dis_ECO_030-r00

The drive motor is connected to the flange and disks (1) of the alternator.

The alternator rotor, started up by the drive motor, generates electricity.

The cables for the electric power supply to the user are connected on the terminal block inside the "terminal box" (2).

The DSR/DER1 digital regulators are equipped with an LED Indicator. During normal operation the LED blinks with a 2-second period and a 50% duty cycle (1 second on, 1 second off), in case of faults it flashes differently.

See diagrams in chapter 10 "Alarm Management".

2.3 Technical Data

2.3.1 Dynamic Data Support (DDS)

For the most up-to-date and detailed technical information, we invite you to visit the support area of the Mecc Alte website:
http://support.meccalte.com/

Here you will find our Dynamic Data Support (DDS), an advanced system for the dynamic generation of technical data sheets. Thanks to an intuitive guided process, you can create a customized sheet by choosing between different available variables and options. This will allow you to obtain data specific to your application and your needs, with automatic calculations updated in real time.

Through the DDS, you can select and configure some technical parameters, while others will be automatically calculated and shown in the generated technical sheet. Among the available data, you will find:

Configurable parameters:

- Frequency
- Type of winding
- Number of phases
- Voltage
- Ambient temperature
- Overtemperature
- Altitude
- International protection class (IP)

Parameters displayed in the technical sheet:

- Overall dimensions
- Noise level
- Weight
- Air volumes
- Resistance of the windings at 20°C ambient temperature

DDS
Dynamic Data Support

Once you have made your selection, the system will automatically calculate the performance based on the specific variants chosen and will send you the customized technical sheet by email.
Please note that all updated and official technical data are available exclusively within this system. To ensure maximum accuracy of the information, we invite you to always consult the DDS to obtain reliable and updated data in real time.
Furthermore, the family sheets with generic voltages are available at the following link:
https://www.meccalte.com/en/products/alternators
To consult the resistance values of the windings, use the direct link:
https://www.meccalte.com/en/resistances

2.3.2 Radial Loads

Maximum allowable radial loads applied to shaft projection, for double-bearing alternators.

Series	Radial force [N]
ECO 43	19000
ECO 46	30000

2.3.3 Alignment tolerances in B3B14

Tolerance table of drive motor alignment with the alternator.


RPM	Radial tolerance (mm)	Angular tolerance (mm / 100 mm)
1200	0.08	0.05
1500	0.06	0.05
1800	0.05	0.05
3000	0.04	0.05
3600	0.03	0.05

2.3.4 Materials

The table below contains the approximate percentages of the materials used in Mecc Alte S.p.A's alternators.


Material	Percentage
Steel Parts	45%
Cast Iron Parts	20%
Copper Parts	20%
Aluminum Parts	10%
Plastic Parts	3%
Electronic parts	2%

2.4 Environmental operating conditions



Max ambient temperature to guarantee the nominal power: 40°C

Max operating altitude to guarantee the nominal power: Less than 1000 m.



Install the alternator in a well-aired room. Insufficient ventilation may cause overheating and malfunctioning of the alternator.

For the air volumes required see paragraph 2.3.

3 Safety

3.1 General warnings

The alternator may be used only for the purpose for which it was designed and built.

Caution

The ECO series alternators comply with the Directive 2006/42/EC as amended, therefore they do not pose threats to the operators, if installed, used and serviced in accordance with the instructions provided by Mecc Alte and on condition that the safety devices are kept in perfect state of efficiency.

Danger

Install the alternator only after having read and understood all the sections of this manual.

Danger

Do no operate it while under the influence of intoxicating agents that might delay reaction time such as, for instance, alcohol or drugs.

Danger

The alternator installation, operation and maintenance technicians must be adequately qualified specialists who know the characteristics of the alternators.

Warning

Adequate work clothing is recommended. Avoid wearing chains, bracelets, scarves and cumbersome clothing, long hair must be tied.

Warning

Do not neutralize, remove, alter or otherwise render ineffective any safety, protection or control device of the alternator.

Warning

Maintain the work areas and the routes defined for the installation of the alternator always free from materials and/or elements that may hinder the movement of or cause accidents to the operator.

Caution

The work area must always be adequately lit.

Caution

Keep the floor in the operating area always clean and dry to prevent the forklift truck from sliding sideways when in movement.

Danger

Never operate the alternator with wet hands and objects when it is energized.

Warning

Do not lean on and do not step onto the alternator.

Warning

At the end of each operation that involved removal of the safeguards, put them back and make sure that the correct positioning and efficiency are restored.


Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

Danger
Keep the alternator at a safe distance from flammable materials.

Danger
The alternators, when working, release heat even to a high level based on the power being generated. Before touching it wait for the alternator to cool off.

Danger
Working alternators are noisy (see paragraph 2.3.). Install the alternator in insulated rooms and wear earmuffs to operate it.

3.2 Alternator safety devices



dis_ECO_031-r00


The safety devices of the alternator are:
1. Protective net on the front shield.
2. Cover of terminal box.
3. Back latch.

Danger
During the operation of the alternator the safeguards must always be closed.


3.3 Safety tags

Caution
Do not remove under any circumstances the tags attached to the alternator.

The following safety tags are attached to the machine



lay_ECO_004-r00

Pos.	Label	Code	Description
A		XXX	Refer to instruction manual before removing covers
B		XXX	Danger!
C		XXX	Danger - Electricity!
D		XXX	Danger - Hot surface!

Caution
The labels must be replaced if they are worn out or cannot be read anymore.

3.4 Personal Protective Equipment

Caution

The staff in charge with the operation of the alternator must wear the personal protective equipment (PPE) indicated in the table below.

PPE	Operation
	Always wear
	Maintenance or lifting the alternator or its components.

Caution

The operator must observe the accident prevention regulations in force in the specific country where the alternator is used.

Caution

The PPE assigned may not be altered.

The manufacturer disclaims all responsibility for any potential damages caused to people by failure to use the PPE.

3.5 Residual risks

The alternator presents the following residual risks:

Danger

Burning risk. The working alternator may release heat even to a high level.
Before touching the alternator wait for it to cool off.

Caution

Risk of crushing while lifting.
Do not stand under the suspended load, do not come close to it, use adequate PPE.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

4 Transport, handling and storage

The ECO series alternators are delivered by road on pallets, by sea in fumigated wood cases. Other shipment methods available on customer request.
The cases shipped by sea are covered with nylon to avoid salt infiltration that could compromise the correct operation of the alternator.
Any potential replacement parts are however shipped in cardboard packing that is disposed of according to the local regulations.
Packing is always accompanied by a packing list.
Transportation of the packing to the installation place will be provided by the customer.

Upon delivery of the alternator check against the delivery note that there are no missing parts and/or damages; in case there are any, immediately inform the carrier, the insurance company and the reseller or Mecc Alte.

4.1 General warnings

Warning
The instructions of this chapter must be strictly followed when lifting the alternator.

Warning
Use adequate, tested and certified lifting devices.

Warning
Lifting and transportation must be carried out by members of staff who were trained for this purpose.

Warning
To carry out all lifting, transport, and handling operations, wear the PPE required by current regulations (see par. 3.4).

Warning
When lifting the alternator with the forklift truck keep its forks at the longest possible distance one from the other so as to prevent the alternator from falling or sliding off.

Always make sure that the devices and means for packing materials removal, the alternator and any disassembled part are suitable and undamaged.

4.2 Packing materials lifting and transportation

Danger


Pay attention during all transportation and movement operations. Do not stand under suspended loads.

Warning

Check the packing or the documentation attached to it for the weight to lift, the predefined anchor points and use suitable equipment for the lifting.

4.3 Unpacking

Unpack the alternator carefully without breaking/damaging the packing materials. Both the cases (equipped with metal hinges so that they may be folded) and the pallet must be returned to Mecc Alte.



Once the single-bearing alternator is unpacked do not cut the tie strips of the rotor to prevent it from sliding.


4.4 How to dispose of the packing materials

Please recycle the packing materials in accordance with the applicable regulations in the country where the alternator is installed.

4.5 Alternator Movement

Unpacked alternators must always be handled hooking the eyebolts to a lifting device.

For the weight of the alternator see paragraph 2.3



Caution

Lift the alternator to a height not exceeding 30 cm.

Do not add any other load. The eyebolts are only designed for the lifting of the alternator. Do not use the alternator eyebolts to lift the fully assembled machine.

Danger

Once it is coupled to the drive motor, to lift the alternator you must follow the instructions provided by the manufacturer of the fully assembled machine.

4.6 Storage

In case of storage, the alternators, be them packed or not, must be stored in a cool, dry place away from vibrations and never exposed to the elements.

The bearings require special maintenance but it is advisable to turn the shaft around once or twice a month to prevent contact corrosion and grease hardening; before startup, where regular lubrication is required, you must also lubricate it.

After being stored for a long time or if there are obvious signs of humidity/condensation, check the insulation state.

Warning

The insulation test must be carried out by a qualified technician.

Warning

Before carrying out the test you must disconnect the voltage regulator.

If the result of the test is too low (less than 5 MΩ) (EN60204-1) you will have to dry the alternator by blowing 50-60 C° pressurized air into the air intakes and exhausts of the alternator.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

5 Installation instructions / coupling with driving engine

Warning

The final installer is in charge with assembling all the safeguards (disconnect switches, safeguards against direct and indirect contact, safeguards against overcurrent and overvoltage, emergency stop and so on) required to make the machine and the user system comply with the European and International Safety Regulations.


The installation and first startup operations of the fully assembled machine must be carried out by qualified personnel.

Danger

Working alternators are noisy (see paragraph 2.3). Install the alternator in insulated rooms and wear earmuffs to operate it.

5.1 Installation Setup

The alternator must be grounded before installation.Please ensure that the grounding system is effective and it complies with the directives of the country where the alternator will be installed.



dis_ECO_034-r00


The alternator is designed and built to be installed in well-ventilated environments.

See paragraph 2.4

Danger

Install the alternator in a well-aired room. Insufficient ventilation may cause overheating and malfunctioning of the alternator.

Please ensure that the base of the alternator and of the drive motor is calculated so as to support the weight of all potential stresses caused by the operation.



dis_ECO_049-r0(

The installer is in charge with correctly coupling the alternator to the drive motor and all the other measures required to guarantee the correct operation of the alternator and to avoid anomalous stresses that might damage the alternator (such as vibrations, misalignments, various kinds of mechanical stresses).

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

5.2 Mechanical coupling

The coupling of the alternator to the drive motor must be carried out by the end user. It is carried out at his sole discretion, but it must:

- Be realized in accordance with the safety regulations in force.
- Ensure the ideal operating conditions for the alternator (air temperature below 40 °C and air vents not blocked).
- Ensure easy access for its verification and maintenance.
- Be assembled on a strong base able to hold the total weight of the alternator and the drive motor.
- Observe the assembly tolerances.

Control the correct fastening of the discs to the alternator rotor.

See par. 9.7

Imprecise alignment may cause vibrations and damages to the bearings.

Moreover, it is advisable to check the compatibility of the torsional characteristics of the motor / alternator (to be carried out by the customer).

Please see the related technical documentation.

In case of double-bearing alternators, ensure that the radial loads applied to the shaft protrusion do not exceed the admissible values.


See par. 2.3

These values are calculated so as to prevent excessive shaft flexure. The load that may be supported by the bearings is statically and dynamically higher than the one supported by the shaft, however, the presence of excessive vibrations or adverse environmental conditions may reduce the bearing's life or lead to a lower maximum allowable load in proportion to the bearing's life.



During the assembly and disassembly stages of the net, make sure you hold it in position with your hands so as to prevent the elastic net from hitting the operator or anyone else nearby.


In case of single-bearing alternators, during the drive motor coupling stage make sure the rotor does not slip out by keeping the alternator in a horizontal position. Remove the rotor fastening system, if present.



During the mechanical coupling procedures do not use the fan as a lever to turn the rotor.


Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

5.2.1 Alternator Preparation



1. In case of single-bearing alternators remove the safety straps from the rotor. After this operation make sure the rotor does not slip out when handling it.
2. Remove the anti rust protective paint from the flange and, if it is a double-bearing alternator, also from the shaft.
3. In case the alternator was stored for more than one year, before startup lubricate the bearings again if they are not sealed (see paragraph 9.4.1).

5.2.2 Aligning the drive motor to the B3B14 alternator




To ensure regular operation of the B3B14 construction type alternator you must align it to the drive motor in observance of the radial and angular tolerances between the two shafts of the drive motor - alternator.

Misalignment may cause damages to the shaft or to the bearing. For alignment tolerances see 2.3.

5.2.3 Alignment of the driving engine with the alternator in MD35

The (MD35) single-bearing alternator needs a solid flat base in order for the alignment to be realized correctly.

ECO 43 - 46



Always check rigorously the accuracy of the L dimension.

Errors on the L dimension may lead to high axial loads on the bearings and potential damages to the drive motor as well.

For alignment tolerances see par. 2.3

The presence of flexures on the alternator coupling flange may cause high vibrations and in the worst cases even mechanical breaks.

5.2.4 Compensation for thermal expansion

The compensation of thermal expansion is particularly important for the single-bearing generators inasmuch as they are connected directly to the motor and a perfect alignment is essential so as to guarantee the intended useful life of the bearings. In case of double-bearing generators the importance of this aspect depends on the type of motor-generator coupling.
Operating temperatures have a significant impact on the alignment tolerances and must be taken into consideration. Because of them, actually, during the operation, the alternator shaft may be in a different position than its position when powered off.
A compensation of the alignment may therefore be required and it depends on the operating temperatures, on the coupling type, on the distance between the two machines and so on.
The two more important types of thermal expansion to take into consideration are:

- Vertical thermal expansion
- Axial thermal expansion

Vertical thermal expansion
This thermal expansion may cause variations of the radial tolerance value and it may be calculated using the following formula:


$$\Delta H = \alpha \times \Delta T \times H$$

ΔH Variation of height.
α = Coefficient of thermal expansion (value $\alpha = 10 \times 10\text{-}6\ K\text{-}1$ may be used).
ΔT = Difference between the alignment temperature and the operating temperature.
H = Axle height.

Axial thermal expansion
The axial thermal expansion value may diminish the axial tolerance between the two shafts.
It is a very important value inasmuch as, when the whole system reaches a uniform temperature, a very narrow non-operating tolerance may lead to an axial force that may burden the bearings damaging them or causing them to break.
The following formula may be used to calculate it:

$$\Delta L = \alpha \times \Delta T \times L$$

ΔL = Variation of the shaft length.
α = Coefficient of thermal expansion (value $\alpha = 10 \times 10\text{-}6\ K\text{-}1$ may be used).
ΔT = Difference between the alignment temperature and the operating temperature.




L = Shaft length, calculated between the bearing and the drive motor coupling discs.

The variation of the axial tolerance is calculated by relating the axial thermal expansion of the alternator to that of the motor.

6 Electrical connection

The operation must be carried out by an electrical maintenance technician.


The electrical connection shall be provided by the end user and it is carried out at his sole discretion



dis_GEN_003-r00


For the entry into the terminal box it is advisable to use cable glands and cable reliefs in compliance with the specifications of the user country.

See "12 terminal connections" table in this chapter.



dis_GEN_004-r00

The alternators must always be grounded with a grounding conductor of an appropriate size. Use one of the two dedicated terminals (internal/external).



dis_GEN_005-r00

For the electrical connection use adequate cables, sized on the basis of the alternator power. Make the connections to the terminals as shown in the figure.
A) Hexagon nut
B) Plain washer
C) User cable


See paragraph 6.1.

After completing the connection, check the terminal board tightening torques, which must comply with what is indicated in chapter 9.8.
When the connection is finished reassemble the cover of the terminal box.

The user power cables must be wired and supported adequately so as not to cause mechanical stress on the terminal block of the alternator.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

Phase rotation and sequence










All the fans of the ECO alternators are designed to rotate bidirectionally.

Clockwise rotation, seen from the coupling side: the order of the outgoing phases is L1, L2 , L3.

Anticlockwise rotation, seen from the coupling side: the order of the outgoing phases is L3, L2 , L1 (the order is reversed).

Winding connection modalities

The alternators are manufactured with 12 standard outgoing cables in order to allow different voltage output, for instance, 230 V (ΔΔ) / 400 V (YY) / 460 V (Δ) / 800 V (Y) in the 43 and 46 standard series. To pass from a connection to another follow the diagrams shown in the "12 wires connection" table on the next page.

12 wires connection												
Connection				Wiring type							
				T0405S3 (***)				T0405P3 (***)			
Series star		50Hz	L - L	380	400	415	440	760	800	830	880
		50Hz	L - N	220	230	240	254	440	460	480	508
		60Hz	L - L	415	440	460	480	830	880	920	960
		60Hz	L - N	240	254	266	277	480	508	530	554
Parallel star		50Hz	L - L	190	200	208	220	380	400	415	440
		50Hz	L - N	110	115	120	127	220	230	240	254
		60Hz	L - L	208	220	230	240	415	440	460	480
		60Hz	L - N	120	127	133	139	240	254	266	277
Series delta (*)		50Hz	L - L	220	230	240	254	440	460	480	508
		50Hz	L - M	110	115	120	127	254	266	277	290
		60Hz	L - L	240	254	266	277	480	508	530	554
		60Hz	L - M	120	127	133	139	240	252	266	277
Parallel delta (*)		50Hz	L - L	110	115	120	127	220	230	240	254
		60Hz	L - L	120	127	133	139	240	252	266	277
Three phase Zig-zag (**)		50Hz	L - L	330	346	360	380	660	690	720	760
		50Hz	L - N	191	200	208	220	380	400	415	440
		60Hz	L - L	359	380	400	415	720	760	800	830
		60Hz	L - N	207	220	230	240	415	440	460	480
Single phase parallel Zig-zag (*)		50Hz	L - L	220	230	240	254	440	460	480	508
		50Hz	L - M	110	115	120	127	254	266	277	290
		60Hz	L - L	240	254	266	277	880	920	530	554
		60Hz	L - M	120	127	133	139	220	230	240	277
Single phase double delta (*)		50Hz	L - L	220	230	240	254	440	460	480	508
		50Hz	L - M	110	115	120	127	254	266	277	290
		60Hz	L - L	240	254	266	277	440	460	480	554
		60Hz	L - M	120	127	133	139	220	230	240	277


* In case of single-phase loads it is important to remember not to exceed the phase current.
** In the interconnected star connection, the power must be reduced to 0.866 times its nominal value.
*** The highlighted cells represent the nominal values. The other voltage values can be obtained by adjusting the VOLT potentiometer. Voltage variations in relation with the nominal value may though lead to a derating of the machine. For the powers please consult the technical documentation available on www.meccalte.com.

The machine supplied to operate at 50Hz may also work at 60Hz (or vice versa). To obtain the variation you simply adjust the potentiometer to the new nominal voltage value. When passing from 50Hz to 60Hz power may increase by 20% (unvaried current) if the voltage increases by 20%. For alternators specifically built for a 60Hz frequency when passing to 50Hz the voltage and the power must be reduced by 20% in relation to the values referring to 60Hz.

6.1 Terminal board configurations


6.1.1 ECO 43 regulation box and cable connection

PARALLEL STAR CONNECTION




6.1.2 ECO 46 regulation box and cable connection

PARALLEL STAR CONNECTION



6.2 Parallel connection of alternators

In case you want the alternators to operate in parallel you need to use a device to ensure equal droop of output voltages.
The parallel transformer is manufactured with a preset voltage drop of 4% at full load when the power factor is 0.




dis_ECO_051-r00

43 - 46 Series

The device is standard, therefore when two or more alternators of this type must operate in parallel it is enough to just remove the jumper that short-circuits the secondary circuit of the paralleling device.

6.2.1 Installation of a parallel device



dis_ECO_052-r00

- Refer to mounting instructions "Retrofitting PD500 Procedure"
- Connect the power coil windings in series with the phase following the instuctions

For the number of coil turns needed on the transformer please see the drawing table A9865 inside the procedure

- Once received and installed the parallel device, it is important to check, based on the nominal data of the alternator and the adopted reference type, the jumpers J1 and J2 are wired to the correct fastons, according to drawing table A9865, inside the procedure. Also verify that the droop trimmer on the PD-I is positioned at the center.
- Connect the sensing of the alternator to the PD-I module and connect the PD-I module to the sensing terminal of the regulator, following step by step the instructions on the procedure

See Chapter 12.

To enable the paralleling device remove the jumper that short-circuits its secondary winding as shown in the figures beside and in the wiring diagrams.

Warning

For alternators running in parallel to the grid the user must integrate the generation system with adequate protections.

Warning

For these applications it is fundamental to provide protection against the ample excitation variations or an excitation loss relay to avoid serious damages to the alternator.

After having made all the electrical connections and only after having closed the terminal box you may carry out the initial startup test on the system.
Check the no load voltage of the alternator and if necessary act on the electronic regulator VOLT trimmer to move back to the nominal value.

7 Initial start-up instructions

This paragraph only reports the instructions for the initial startup of the alternator. You may find further instructions in the manual of the fully assembled machine.

Warning

The startup, operation and stop maneuvers must be carried out by adequately qualified personnel who has read and understood the safety and technical specifications indicated in this manual.


The tools for system startup, operation and stop shall be provided by the installer.

Check the alignment on the fully assembled machine. See paragraph 5.3.1.

- Check the fastening of the machine to the base with the related tightening torques and the robustness of the base.

Check the tightening torques of the terminal connections and their positioning. See paragraph 9.6.

Before the startup of the fully assembled machine you must make sure that:



- The cooling air intake and exhaust openings are always free. It is recommended to maintain a clear distance of 20cm. For the necessary cooling air volumes see par. 2.3.
- The intake side is away from heat sources. However, if not specifically agreed, the temperature of the cooling air must be equal to the room temperature and anyway lower than 40 °C. The alternator may operate at higher temperatures with an appropriate derating.

During the initial startup that must be carried out at lower speed, the installer will have to make sure there are no anomalous noises. In case of anomalous noises stop the system immediately and make adjustments to improve the mechanical coupling.

The rotors of the Mecc Alte alternators and the alternators themselves comply with the regulations (see paragraph 1.5). This means that the vibrations generated by the Mecc Alte alternators are very limited and compliant with the regulations.
Potential excessive vibrations are ascribable to the drive motor or to an erroneous motor-alternator coupling and they may cause damages or even breaks to the bearings.

The installer is responsible for following the regulations when assessing and measuring the vibrations on the fully assembled machine (see paragraph 1.5).

After the initial startup

After the initial startup of the fully assembled machine it is necessary to carry out the following verifications:

- Make sure everything works correctly.
- Monitor the vibration level and potential high temperatures of the windings and of the bearings.

In case the alternator, during operation, goes into protection mode for anomalous voltage, troubleshot the fault before initiating another startup.

See "Problems, causes and solutions" chapter 11.

8 Electronic regulators

8.1 DSR digital regulator

The operation must be carried out by an electrical maintenance technician.


For further details on the regulators please refer to the specific manual.

Danger

Check with the alternator on.

Carefully perform the test, use adequate PPE such as for instance insulating gloves.

Voltage testing is performed off-load with the alternator running at nominal frequency. To obtain voltage regulation use the VOLT potentiometer of the electronic regulator.



1. Regulation of overload protection (AMP).
2. Regulation of low frequency protection (Hz).
3. Regulation of stability (STAB).
4. Regulation of voltage (VOLT).
5. Terminals 10 and 11 for remote regulation of voltage.

Self-regulation is achieved through the DSR digital regulator that guarantees, under static conditions, a ± 1% voltage accuracy with any power factor and with a speed variation ranging from –5% to + 20%.

Remote Regulation

To achieve remote regulation insert a 10KΩ potentiometer in the dedicated terminals 10-11.

8.1.1 Stability setting

The alternators are part of a system that can be outlined as a motor + alternator. The alternator may therefore exhibit instabilities of the rotation regime and of the voltage due to the irregular operation of the motor it is connected to.
There is a potentiometer dedicated to the adjustment of this stability (STAB potentiometer), because the alternator voltage and motor speed regulation systems may go into conflict, causing both speed and voltage oscillations.
It is important to stress that Mecc Alte's alternators are tested using an electric motor, not a heat engine. Therefore, STAB adjustment is set correctly for the alternator driven by an electric motor.
General instructions to follow in case of instability problems:

1. Check the STAB potentiometer setting and make sure it corresponds to the settings reported in the tables below.
2. If there is no correspondence, reset the potentiometer to the value indicated in the table below; in case of missing information position in the middle.
3. If the problem persists, rotate the potentiometer anticlockwise a notch and repeat the test.
4. If no differences are noticed or the differences are minimal, rotate another notch anticlockwise; continue this procedure until the problem is solved.
5. If by rotating the potentiometer anticlockwise, the voltage instability increases, set the potentiometer as indicated at point 2. Rotate the potentiometer clockwise a notch and repeat the test
6. If there are no changes or they are minimal, rotate another notch clockwise and repeat the test.
7. Continue this procedure until the problem is solved.
8. Check the STAB potentiometer setting and make sure it corresponds to the settings reported in the tables below.

8.1.2 Protections

To avoid anomalous and dangerous operation of the alternator, the DSR digital regulator is equipped with a low speed protection and an overload protection.
Low speed protection
Its intervention is instantaneous and it causes the reduction of the alternator voltage when the frequency drops by 4 ±1 % under the nominal frequency.
The intervention threshold is set using the "Hz" potentiometer.
Overload protection
A dedicated circuit compares the partialized excitation voltage. If the preset value for this voltage (a value corresponding with a load current value equal to 1.1 times the current indicated on the alternator tag) is exceeded for more than 20 seconds, the regulator steps in lowering the alternator voltage and subsequently limiting the current within a safe value range.
The delay is expressly introduced to allow the motors that normally start in 5÷10 seconds to pick-up. This intervention threshold may be adjusted using the "AMP" potentiometer.
Causes that lead to protection intervention.

Instantaneous protection intervention for low speed	1 - Speed reduced by 4 ± 1 % as compared to the rated data.
Delayed protection intervention for overload	2 - Overload of 10% as compared to the rated data.
	3 - Power factor (cos φ) lower than the rated data.
	4 - Environmental temperature above 50°C.
Intervention of both protections	5 - Combination of factor 1 and factors 2, 3, 4.

In case both protections intervene, the voltage supplied by the alternator will drop to a value that depends on the size of the fault.
Voltage will be automatically restored to its nominal value when the fault is solved.

8.1.3 Inputs and outputs: technical specifications

TABLE 1 CONNECTOR CN 1				
Term.(*)	**Name**	**Function**	**Specifications**	**Notes**
1	Exc-	Excitation	Continuous Rating: 5 Adc max Transitory Rating: 12 Adc at peak	
2	Aux / Exc+			
3	Aux / Exc+	Power	Frequency: from 12Hz to 72Hz Range: 40 Vac - 270 Vac	
9	Aux / Neutral			
4	F_Phase	Sensing	Range: 140 Vac - 280 Vac Burden: <1VA	Measurement of average value (rectified) or actual effective value for voltage adjustment
5	F_Phase			
6	H_Phase		Range: 70 Vac - 140 Vac Burden: <1VA	
7	H_Phase			
8	Aux / Neutral			
10	Vext / Pext	Input for remote voltage control	Type: Not insulated Range: 0 - 2,5 Vdc or 10 K Potentiometer Adjustment: from - 14% to + 14% (***) Burden: 0-2 mA (sink) Max length: 30m (**)	Tolerates voltages from -5V to +5V but for values exceeding the range it is automatically disabled
11	Common			
12	50 / 60 Hz	50/60Hz Jumper input	Type: Not insulated Max length: 3m	Selection of underspeed protection threshold 50x(100%-αHz%) or 60x(100%-αHz%) αHz% is the position relative to the Hz trimmer or the percentage value of parameter 21
13	Common			
14	A.P.O.	Active protections output	Type: Non-insulated open collector Current: 100 mA Voltage: 30V Max length: 30m (**)	Active level (****), activating alarm and delay time programmable
15	Common			

tab_ECO_008-r00

* They are connected together on the board the following terminals: 2 and 3; 4 and 5; 6 and 7; 8 and 9; 11 and 13 and 15.
** With an external EMI SDR 128/K filter (3m without EMI filter).
*** Starting from version 10 of the Firmware. It is important not to exceed by more than ± 10%.
**** Starting from rev. 18 of the Firmware.

The regulators mounted on board the alternators prove to be calibrated during the final test. For loose regulators (for instance spare parts) or if wiring or calibration variations are required, you will have to perform an adequate setting of the regulator to guarantee its correct operation.

The basic settings may be performed directly on the regulator through the 4 trimmers (VOLT - STAB - Hz - AMP), the 50/60 jumper and the Vext input.
More detailed settings and measures may be performed only via software using, for instance, the Mecc Alte USB2DxR communication interface and the DxR_Terminal software.

Vext Input

The Vext input (connector CN1 terminals 10 and 11) allows the analog remote control of the output voltage through a 10Kohm potentiometer with a variation range that may be programmed via parameter 16 (by default the setting is ± 14% starting from version 10 of the Firmware) in relation to the value set by the VOLT trimmer or by parameter 19.

If you want to use continuous voltage, it will have an effect if contained within the range from 0V to +2,5V.
The input tolerates voltages from -5V to + 5V, but for values exceeding the 0V / +2.5V limits (or in case of disconnection) there are two available options:

- Not to consider the value (default configuration) and go back to the regulation of the voltage value set through the trimmer (if enabled) or through parameter 19.
- Maintain the minimum (or the maximum) reachable voltage value.

The two options can be set through the RAM Voltage CTRL flag in the Configuration Menu corresponding to the B7 bit of the configuration word P[10].

The continuous voltage supply must be able to absorb at least 2 mA.
In the regulation it is advisable not to exceed by more than ± 10% the nominal voltage value of the alternator.

50/60 Signal

A jumper placed on the 50/60 input (connector CN1 terminals 12 and 13) entails the switching of the low speed protection threshold from 50·(100%-αHz%) to 60·(100%-αHz%), where αHz% is the related position of the HZ trimmer.

APO Contact

Acronym for Active Protection Output: (connector CN1 terminals 14 and 15) uninsulated open collector 30V-100mA transistor, by default normally closed (starting from revision 18 of the firmware; for firmware revisions up to 17 the transistor is normally open and it closes in case of an active alarm). It opens (with a software programmable delay of 1 to 15 seconds) when, one or several alarms, that may be selected separately via software, are active.

VOLT Trimmer

It allows regulation from approximately 70V to approximately 140V when terminals 4 and 5 are used for the sensing or from approximately 140V to approximately 280V when terminals 6 and 7 are used.

STAB Trimmer

It regulates the dynamic response (droop) of the alternator under transient conditions.

AMP Trimmer

It regulates the excitation overcurrent protection intervention threshold.
To calibrate the overload protection, perform the following procedure:

1. Rotate the Hz trimmer anticlockwise.
2. Apply nominal load to the alternator.
3. Reduce the speed by 10%.
4. Rotate the AMP trimmer completely in anticlockwise direction.
5. After a few seconds you should notice a reduction of the alternator voltage value and the activation of alarm 5 (indicated by a change in the LED flashing).
6. In this case slowly rotate the "AMP" trimmer in clockwise direction until you get the output voltage value to 97% of its nominal value: alarm 5 is still active.
7. If you go back to nominal speed, alarm 5 disappears after a few seconds and the alternator voltage rises back to the nominal value.
8. Readjust the Hz trimmer as indicated.

Hz Trimmer

It allows the regulation of the low speed protection intervention threshold up to -20% compared to the nominal speed value set by the 50/60 jumper (at 50 Hz the threshold may be adjusted from 40Hz to 50Hz, to 60 Hz the threshold may be adjusted from 48Hz to 60Hz).

The intervention of the protection diminishes the alternator voltage. Perform the adjustment as follows:

1. Rotate the Hz trimmer anticlockwise.
2. If the machine must operate at 60 Hz, make sure the jumper between terminals 12 and 13 of the CN1 connector is inserted.
3. Take the alternator to a speed equal to 96% of its nominal speed.
4. Slowly turn the "Hz" trimmer. Rotate it in clockwise direction until the alternator voltage starts to diminish and at the same time make sure the LED starts blinking fast.
5. By increasing the speed, the voltage of the generator should go back to normal and alarm should disappear.
6. Take the speed back to the nominal value.

Even if still continuing to regulate the voltage, the DSR goes into switch-off mode when the frequency decreases under 20 Hz. To restore it you need to shut down the alternator completely.

Alarm management

See par. 10.1

Wiring diagrams

See par. 12.1

8.2 DER1 digital regulator

The operation must be carried out by an electrical maintenance technician.


For further details on the regulators please refer to the specific manual.

Danger

Check with the alternator on.

Carefully perform the test, use adequate PPE such as for instance insulating gloves.

Voltage testing is performed off-load with the alternator running at nominal frequency. To obtain the voltage regulation use the VOLT potentiometer of the electronic regulator.



dis_ECO_020-r00

1. Regulation of the overload protection (AMP).
2. Regulation of low frequency protection (Hz).
3. Regulation of stability (STAB).
4. Regulation of voltage (VOLT).
5. Terminals 29 and 30 for remote regulation of voltage.

The self-regulation achieved through the DER1 digital regulator guarantees, under static conditions, a ± 1% voltage accuracy with any power factor and with a speed variation ranging from –5% to + 20%.

Remote Regulation

To obtain a regulation within ±14% of the nominal value insert a 100KΩ potentiometer in the dedicated terminals 29-30.

To obtain a regulation within ±7% of the nominal value insert a 25KΩ linear potentiometer in series with a 3.9KΩ resistor to halve the effect of the external potentiometer.

DER2 Digital Regulator

The DER2 regulator is assembled as a normal DER1 except for the USB2DxR communication interface that is substituted by the new 1X5 p.2.54 mm strip connector that is mounted directly on the card. The alternators being equal, the DER2 regulator settings are the same as DER1.

8.2.1 Stability setting

The alternators are part of a system that can be outlined as a motor + alternator. The alternator may therefore exhibit instabilities of the rotation regime and of the voltage due to the irregular operation of the motor it is connected to.
Alternator
It is important to stress that Mecc Alte's alternators are tested using an electric motor, not a heat engine. Therefore, STAB adjustment is set correctly for the alternator driven by an electric motor.
General instructions to follow in case of instability problems:

1. Check the STAB potentiometer setting and make sure it corresponds to the settings reported in the tables below.
2. If there is no correspondence, reset the potentiometer to the value indicated in the table below; in case of missing information position in the middle.
3. If the problem persists, rotate the potentiometer anticlockwise a notch and repeat the test.
4. If no differences are noticed or the differences are minimal, rotate another notch anticlockwise; continue this procedure until the problem is solved.
5. If by rotating the potentiometer anticlockwise, the voltage instability increases, set the potentiometer as indicated at point 2. Rotate the potentiometer clockwise a notch and repeat the test
6. If there are no changes or they are minimal, rotate another notch clockwise and repeat the test.
7. Continue this procedure until the problem is solved.
8. Check the STAB potentiometer setting and make sure it corresponds to the settings reported in the tables below.

8.2.2 Protections

To avoid anomalous and dangerous operation of the alternator, the DER1 digital regulator is equipped with a low speed protection and an overload protection.

Low speed protection
Its intervention is instantaneous and it causes the reduction of the alternator voltage when the frequency drops by 4 ±1 % under the nominal frequency.
The intervention threshold is set using the "Hz" potentiometer.

Overload protection
A dedicated circuit compares the partialized excitation voltage. If the preset value for this voltage (a value corresponding with a load current value equal to 1.1 times the current indicated on the alternator tag) is exceeded for more than 20 seconds, the regulator steps in lowering the alternator voltage and subsequently limiting the current within a safe value range.
The delay is expressly introduced to allow the motors that normally start in 5÷10 seconds to pick-up. This intervention threshold may be adjusted using the "AMP" potentiometer.
Causes that lead to protection intervention.

Instantaneous protection intervention for low speed	1 - Speed reduced by 4 ± 1 % as compared to the rated data.
Delayed protection intervention for overload	2 - Overload of 10% as compared to the rated data.
	3 - Power factor (cos φ) lower than the rated data.
	4 - Environmental temperature above 50°C.
Intervention of both protections	5 - Combination of factor 1 and factors 2, 3, 4.

In case both protections intervene, the voltage supplied by the alternator will drop to a value that depends on the size of the fault.
Voltage will be automatically restored to its nominal value when the fault is solved.

8.2.3 Inputs and outputs: technical specifications

TABLE 1 CONNECTOR CN 1				
Term. (*)	**Name**	**Function**	**Specification**	**Notes**
1	Exc-	Excitation	Continuous Rating: 5 Adc Transitory Rating: 12 Adc at peak	
2	Aux / Exc+			
3	Aux / Exc+	Power	40 ÷ 270 Vac Frequency 12 ÷ 72Hz (**)	(*)
4	UFG	Sensing Range 2	Range 2: 150 ÷ 300 Vac Burden: < 1VA	U channel
5	UFG			
6	UHG	Sensing Range 1	Range 1: 75 ÷ 150 Vac Burden: < 1VA	
7	UHG			
8	UHB	Jumper Range 1		Short for sensing 75 ÷ 150 Vac
9	UFB			
10	UFB		Board reference	Star point of YY or Y connection, in common with board feeding (*)
11	UFB			
12	UFB			
13	/		Not present	
14	VFG	Sensing	Range 1: 75 ÷ 150 Vac Burden: < 1VA	V channel, to be connected in parallel to U channel in case of single phase sensing
15	VHG	Sensing Range 1		
16	VHB		Range 2: 150 ÷ 300 Vac Burden: < 1VA	
17	VFB	Range 2		
18	/		Not present	
19	WFG	Sensing	Range 1: 75 ÷ 150 Vac Burden: < 1VA	W channel, unused (with shorted inputs) in case of single phase sensing
20	WHG	Sensing Range 1		
21	WHB		Range 2: 150 ÷ 300 Vac Burden: < 1VA	
22	WFB	Range 2		

tab_ECO_010-r00

* They are connected together on the board the following terminals: 2 and 3; 4 and 5; 6 and 7; 9 and 10, 11 and 12.
** Minimum supply voltage 40Vac at 15Hz, 100V at 50Hz, 115V at 60Hz.

TABLE 2 CONNECTOR CN 3				
Term. (*)	**Name**	**Function**	**Specifications**	**Notes**
23	Common	Active protections output	Type: Non-insulated open collector Current: 100 mA Voltage: 30 V Max length: 30m (***)	Active level(******), activating alarm and delay time programmable
24	A.P.O.			
25	Common	Jumper 50/60 Hz	Type: Not insulated Max length: 3m	Selection of underspeed protection threshold
26	50/60 Hz			
27	0EXT	Jumper for remote voltage control 0÷2,5 Vdc	Type: Not insulated Max length: 3m	Short for 0÷2,5Vdc input or potentiometer
28	JP1			
29	0EXT	Input for remote voltage	Type: Not insulated Max length: 30m (***)	Regulation: ± 10% (*****)
30	PEXT	Input for remote voltage control 0÷2,5 Vdc or Pext	Input: 0÷2,5 Vdc or 100K Potentiometer	Burden: 0÷1mA (sink)
31	JP2	Pext jumper	Type: Not insulated Max length: 3m	Short for 0÷2,5Vdc input or potentiometer
32	± 10 V	control ± 10 Vdc	Input: ± 10 Vdc	Burden: ± 1mA (source/sink)

tab_ECO_011-r00


*** With an external EMI filter (3m without the EMI filter).
**** 50·(100%-αHz%) or 60·(100%-αHz%) where αHz% is the position in relation to the Hz trimmer or the percentage value of the P[21] parameter.
***** Values not to be exceeded, the actual range depends on the P[16] parameter.
**** Starting from rev. 18 of the Firmware.


The regulators mounted on board the alternators prove to be calibrated during the final test. For loose regulators (for instance spare parts) or if wiring or calibration variations are required, you will have to perform an adequate setting of the regulator to guarantee its correct operation.

The basic settings may be performed directly on the regulator through the 4 trimmers (VOLT - STAB - Hz - AMP), the 50/60 jumper, JP1, JP2 and the Pext input.
More detailed settings and measures may be performed only via software using, for instance, the Mecc Alte USB2DxR communication interface and the DxR_Terminal software.

Remote control of voltage

The Pext inputs (terminal 30) and ±10V (terminal 32) allow the analog remote control of the output voltage through a continuous voltage or a potentiometer, with a programmable variation range with respect to the value set through the trimmer (by default) or through the P[19] parameter.





If you want to use a continuous voltage it will have an effect if contained within the 0Vdc/2,5Vdc o -10Vdc/+10Vdc range, if connected respectively between the terminals 30 and 29, or 32 and 29 and based on the presence or absence of the JP1 and JP2 jumpers.

For values that exceed the above-mentioned limits (or in case of disconnection) you have two available options:

- Not to consider the value and go back to the regulation of the voltage value set through the trimmer (if enabled) or through parameter P[19], fig. 1.
- Maintain the minimum (or the maximum) reachable voltage value, fig. 2.

The second option can be set through the RAM Voltage CTRL flag in the Configuration Menu corresponding to the B7 bit of the configuration word P[10].

See the technical guide: DER 1 Digital Regulator.

The continuous voltage supply must be able to absorb at least 2 mA.
In the regulation it is advisable not to exceed by more than ± 10% the nominal voltage value of the alternator.

50/60 Signal

A jumper placed on the 50/60 input (terminals 25 and 26) entails the switching of the low speed protection threshold from 50·(100%-αHz%) to 60·(100%-αHz%), where αHz% is the related position of the HZ trimmer.

APO Contact

Acronym for Active Protection Output: (connector CN3 terminals 23 and 24) uninsulated open collector 30V-100mA transistor, by default normally closed (starting from revision 19 of the firmware; for firmware revisions up to 18 the transistor is normally open and it closes in case of an active alarm). It opens (with a software programmable delay of 1 to 15 seconds) when, one or several alarms, that may be selected separately via software, are active.

VOLT Trimmer
It allows regulation from approximately 75V to approximately 150V when terminals 6/7 - 10/11/12 (with an 8-9 jumper) 15-16 and 20-21 are used for the sensing or from approximately 150V to approximately 300V when terminals 4/5 - 9/10/11/12, 14-17 and 19-22 are used.

STAB Trimmer
It regulates the dynamic response (droop) of the alternator under transient conditions.
It must not be rotated to minus two notches counted in clockwise direction.

AMP Trimmer
It regulates the excitation overcurrent protection intervention threshold.
To calibrate the overload protection, perform the following procedure:

1. Rotate the AMP trimmer completely in clockwise direction.
2. Feed the alternator an overload having cos phi = 0.8 or cos phi = 0 respectively equal to 125% or 110% of the nominal load.
3. After two minutes slowly turn the AMP trimmer anti-clockwise until you get a reduction of the generator's voltage value and the activation of alarm 5 (visible through a change in the LED flashing)
4. Adjust the AMP trimmer so as to get an output voltage value of 97% of the nominal value: alarm 5 is still active
5. If the load is removed, alarm 5 disappears after a few seconds and the generator voltage goes back to the nominal value.

Hz Trimmer
It allows the regulation of the low speed protection intervention threshold up to -20% compared to the nominal speed value set by the 50/60 jumper (at 50 Hz the threshold may be adjusted from 40Hz to 50Hz, to 60 Hz the threshold may be adjusted from 48Hz to 60Hz).
The intervention of the protection diminishes the alternator voltage. Perform the adjustment as follows:

1. Rotate the Hz trimmer anticlockwise.
2. If the machine must operate at 60 Hz, make sure the jumper between terminals 25 and 26 is inserted.
3. Take the alternator to a speed equal to 96% of its nominal speed.
4. Slowly turn the "Hz" trimmer. Rotate it in clockwise direction until the alternator voltage starts to diminish and at the same time make sure the LED starts blinking fast.
5. By increasing the speed, the voltage of the generator should go back to normal and alarm should disappear.
6. Take the speed back to the nominal value.

Even if still continuing to regulate the voltage, the DER1 goes into switch-off mode when the frequency decreases under 20 Hz. To restore it you need to shut down the alternator completely.

Alarm management

See paragraph 10.2.

Wiring diagrams

See par. 12.2

8.3 UVR6-SR7 analog regulators

The operation must be carried out by an electrical maintenance technician.


For further details on the regulators please refer to the specific manual.

Danger

Check with the alternator on.

Carefully perform the test, use adequate PPE such as for instance insulating gloves.

Voltage testing is performed off-load with the alternator running at nominal frequency. To obtain the regulation of voltage within ±5% of the nominal value turn the voltage potentiometer of the electronic regulator.



dis_ECO_025-r00

The following regulators are obsolete and were replaced by DSR/DER1 electronic regulators.

The U.V.R.6/1-F e S.R.7/2-G regulators may be equally used with the ECO series without altering performance.


The U.V.R.6/1-F was standard on models, while the S.R.7/2-G on series.

The two regulators are perfectly equal as far as performance is concerned but they are different in terms of signaling and reference.

Remote Regulation

To obtain the remote regulation of voltage within a ÷ 5% range of the nominal value, insert:

- A 100KΩ potentiometer for the alternators equipped with 6 terminals
- A 100KΩ potentiometer in series with a 100KΩ resistor for the alternators with 12 terminals.




dis_ECO_026-r00

For a correct operation of the alternator connect the remote potentiometer as follows:

- Rotate the VOLT trimmer of the electronic regulator completely in anticlockwise direction.
- Position the external potentiometer at half scale and connect it with the corresponding terminals of the electronic regulator.
- Adjust the voltage to the nominal value through the VOLT trimmer of the electronic regulator.

Protections

To avoid anomalous and dangerous operation of the alternator, the U.V.R.6/1-F - S.R.7/2-G. analogic regulators are equipped with a low speed protection and an overload protection.



dis_ECO_027-r00

Low speed protection

Its intervention is instantaneous and it causes the reduction of the alternator voltage when the frequency under 10% of the nominal frequency.

The intervention threshold is set using the "Hz" potentiometer.


Overload protection

A dedicated circuit compares the partialized excitation voltage. If the preset value for this voltage (a value corresponding with a load current value equal to 1.1 times the current indicated on the alternator tag) is exceeded for more than 20 seconds, the regulator steps in lowering the alternator voltage and subsequently limiting the current within a safe value range.

The delay is expressly introduced to allow the motors that normally start in 5÷10 seconds to pick-up. This intervention threshold may be adjusted using the "AMP" potentiometer.

If the alternator is used in single phase or with voltages different than the ones set by the manufacturer, a readjustment of the AMP and STAB potentiometers might be necessary.

U.V.R.6/1-F Signals


dis_ECO_028-r00

The U.V.R.6/1-F regulator has the following characteristics:

1. Possibility to also have a three phase reference besides the single phase one.
2. LED signals of auto diagnosis that indicate the operation conditions of the machine:

- A green LED: if normally lit it indicates normal operation of the alternator.
- A red LED: when lit it indicates the intervention of the low speed protection.
- A yellow LED: when lit it indicates the intervention of the overload protection.

During normal operation of the alternator, only the green LED must be lit.

All these signals may be managed remotely and used for various purposes through the use of the SPD96/A device, available on request.


Causes that lead to protection intervention.

Instantaneous protection intervention for low speed	1 - Speed reduced by 10% as compared to the rated data.
Delayed protection intervention for overload	2 - Overload of 20% as compared to the rated data.
	3 - Power factor (cos φ) lower than the rated data.
	4 - Environmental temperature above 50°C.
Intervention of both protections	5 - Combination of factor 1 and factors 2, 3, 4.

In case both protections intervene, the voltage supplied by the alternator will drop to a value that depends on the size of the fault.

Voltage will be automatically restored to its nominal value when the fault is solved.

Optionals



dis_ECO_029-r00

All the alternators in the ECO series may also be operated with manual regulation, without the assistance of external supplies and with the simple use of one rheostat.

See par. 12.4

8.4 M2K / M3K digital regulator

The operation must be carried out by an electrical maintenance technician.

Danger

Check with the alternator on.

Carefully perform the test, use adequate PPE such as for instance insulating gloves.

For information regarding the MxK regulator line, please refer to the regulator manual that you will find in our download area at the following link:

https://www.meccalte.com/en/download-area





9 Maintenance

9.1 General warnings

Warning
Before performing any maintenance, carefully read chapter 3 "Safety" of this manual.

Warning
The authorized operators are only allowed to carry out the works they are specifically qualified for on the alternator and wear the required PPE (personal protective equipment).

Warning
Always disconnect the alternator from power supplies before carrying out any maintenance and/or replacement operation.

Warning
The alternators, when working, release heat even to a high level based on the power being generated. Before touching it wait for the alternator to cool off.

Danger
It is forbidden to pass through or stand under the alternator during the lifting and transportation stages.

It is advisable for the maintenance technician to keep a register of all the interventions.

The ECO series alternators are built to operate without maintenance for a long time.
The maintenance interventions on the Mecc Alte alternator are divided into ordinary and extraordinary.

9.2 Maintenance summary table

9.2.1 Ordinary maintenance summary table

Acronyms of the intervention types: E = Electrical; M = Mechanical

Type	Description	Periodicity	Reference
M	General Cleaning	Every 400 hours	9.3.1
M	Air filter cleaning (if present)	Every 400 hours of use	9.3.2
M	Visual Inspection	Every 2500 hours	9.3.3
M	Verification of winding state	Every 2500 hours	9.3.4
M	Verification of correct alternator operation	Every 2500 hours	9.3.5
M	Tightening torque check	Every 2500 hours	9.3.6

9.2.2 Extraordinary maintenance summary table

Acronyms of the intervention types: E = Electrical; M = Mechanical; S = Software

Type	Description	Periodicity	Reference
M	Maintenance of bearings and possible replacement	Every 4000 hours	9.4.1
E	Winding state and diode bridge fastening check	Every 8000 hours / 1 year	9.4.2
S	Copy of the alarms of the digital regulator	Every 8000 hours / 1 year	9.4.3
M	Check correct fastening of PMG (optional component)	Every 8000 hours / 1 year	9.4.4
M	Cleaning of windings	Every 20000 to 25000 hours	9.4.5

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.2.3 Summary table of maintenance operations in case of failure

Acronyms of the intervention types: E = Electrical; M = Mechanical

Type	Description	Periodicity	Reference
M	Fan replacement assembling	-	9.5.1
E	Check and possible replacement of diode bridge	-	9.5.2
M	Mechanical disassembly for inspection (series 43-46)	-	9.5.3
M	Mechanical assembly (43-46 series)	-	9.5.4
M	PMG disassembling	-	9.5.5
M	PMG assembly (series 43–46)	-	9.5.6
M	Disc Holder Hub Removal (43 and 46 series)	-	9.5.7
E	Loss of residual magnetism (re-excitation of the machine)	-	9.5.8
E	Check and replacement of voltage regulator	-	9.5.9
E	DSR test and setup on test bench	-	9.5.10
E	DER1 test and setup on test bench	-	9.5.11
E	DER 2 test and setup on test bench	-	9.5.12
E	Main stator windings voltage test	-	9.5.13

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.3 Routine maintenance

Ordinary maintenance means the set of operations that are carried out on a regular basis.
Their purpose is to maintain the alternator in good operational state.

Caution

Carry out ordinary maintenance with accuracy and as often as specified by the manufacturer.

9.3.1 General Cleaning

The intervention described in this paragraph refers only to the alternator, the frequency proposed must be adapted to the actual conditions and the frequency of use.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

Warning

Never use liquids or water.

Warning

Never clean the internal electrical components of the terminal box with pressurized air because short circuits or other malfunctions may occur.

Warning

Move close to the alternator only when it has zero power supply and it is at room temperature. It is only now that you may clean it on the outside with pressurized air.

Carry out general cleaning of the alternator and the surrounding area.
During the cleaning check the state and make sure that the various parts of the alternator are undamaged.
In case of anomalies or damages contact the maintenance technician for a potential intervention/replacement.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.3.2 Air filter cleaning (if present)


Type of intervention	Operator	Periodicity
		Every 400 hours of use
PPE to wear		**Materials and equipments**
		Cleaning tools

Danger


Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

The intervention periodicity indicated refers to critical environmental conditions. Adapt the periodicity based on the actual conditions of use.

The air filters are accessories that are assembled on customer request.
Air filters must be regularly cleaned because they hold within a net that must be kept clean to guarantee the efficiency of the filter and the consequent good operation of the alternator.
The periodicity of intervention on the air filters will depend on the severity of the conditions at the installation place. However a regular inspection of these components will allow you to determine if you should intervene.



Open the four latches (1).
Remove the internal components of the filter and clean.



Remove the cover (1).
Remove the filter elements (2) and (3) and clean.

Reassemble everything according to the initial configuration.

9.3.3 Visual Inspection

Type of intervention	Operator	Periodicity
		Every 2500 hours.
PPE to wear		**Materials and equipments**
		Workshop tools.


- Check for the presence of anomalies such as cracks, rust, leakages and any other anomalous event.
- Check the tightening of the power cables and of the regulator cables.
- Check the state of the insulations of the power cables and of the regulator cables (overtemperature, rubbing).

9.3.4 Verification of winding state


Type of intervention	Operator	Periodicity
		Every 2500 hours.
PPE to wear		**Materials and equipments**
		"Megger" Tester or similar to 500V in continuous voltage.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.



Before carrying out the verification disconnect the voltage regulator (fig. A), the radio interference filters (fig. B) and all the other potential devices electrically connected to the windings to check.



Measure insulation resistance to ground.

The measured value of resistance to ground of all the windings must be higher than 5MΩ.

If the value is lower than 5MΩ dry the windings with a jet of hot air at 50-60°C. Direct the jet of air into the air intakes and exhausts of the alternator.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.3.5 Verification of correct alternator operation

Type of intervention	Operator	Periodicity
		 Every 2500 hours.
PPE to wear		**Materials and equipments**
		Workshop tools.

Check whether the alternator operates regularly without noises or anomalous vibrations.
In presence of noises and/or vibrations, check:

- The balancing of the rotor.
- The condition of the alternator bearings. Replace them if necessary (see par. 9.4.1).
- The alignment of the couplings.
- The potential presence of stresses in the heat engine.
- The potential presence of stresses in the anti-vibration supports.
- The functional data (see alternator nameplate par. 1.6).

9.3.6 Tightening torque check

Type of intervention	Operator	Periodicity
		 Every 2500 hours.
PPE to wear		**Materials and equipments**
		The torque wrench.



Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

- Check the tightening status of the bolts (see par. 9.6).
- Check the electrical connections.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.3.7 External and internal cleaning of the alternator

Type of intervention	Operator	Periodicity
		 Every 15 days

PPE to wear	Materials and equipments
	• Industrial vacuum cleaner equipped with dust filter • Antistatic brushes • Compressed air (not to be used on the active parts of the wound components, according to the methods indicated below).

Method of intervention:
For cleaning the external and internal surfaces of the alternator, it is recommended to use industrial vacuum cleaners in order to avoid the movement of dust and any residues inside the slots of the windings, a condition that could compromise the levels of electrical insulation.

The use of compressed air to clean the windings and internal parts is not recommended because:
- It can push dirt into the winding slots, reducing the effectiveness of the electrical insulation;
- If it does not come from systems equipped with dryers (for example mobile compressors without water separators), it can contain condensation and introduce humidity into the electrical components, with the risk of contamination and reduction of insulation.

The use of compressed air should be avoided or limited exclusively to cleaning external surfaces, provided that:
- The air comes from systems equipped with a dryer and suitable filters;
- The pressure used is controlled to avoid mechanical damage to external components;
- It is not directed directly towards openings, slots or ventilation grilles, to avoid the entry of dust into the alternator and active components.

The use of any type of pressure washer and cleaning liquids near the alternator is absolutely prohibited. The standard protection level of the alternator is IP23 and therefore using liquids could cause anomalies or even short circuits.

The intervention periodicity indicated refers to critical environmental conditions. Adapt the periodicity based on the actual conditions of use.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.4 Extraordinary maintenance

Caution
Carry out extraordinary maintenance with accuracy and as often as specified by the manufacturer.

Warning
All the maintenance intervals described below refer to a normal use of the alternator. In case it is used in more severe conditions (high humidity, temperature or dust) it is necessary to check it more often.

9.4.1 Maintenance of bearings and possible replacement

Type of intervention	Operator	Periodicity
		 Every 4000 hours
PPE to wear		**Materials and equipments**
		SKF LGMT2 or ENS or equivalent greases.

Danger
Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

- Check the state of the bearings.
- Lubricate the bearings if they are equipped with a lubricator.

Bearing lubrication table

Alternator	Type	Bearing type		Lubrication interval hours		Grease grams	
		Coupling side	Opposite coupling side	Coupling side	Opposite coupling side	C.S.	O.C.S.
ECO 43	Standard	6324.2RS	6322.2RS	- (*)	- (*)	-	-
	Optional	6324	6322	4000 (**)	4000 (**)	70	60
ECO 46	Standard	6330M	6324.2RS	4000 (**)	- (*)	90	-
	Optional	6330M	6324	4000 (**)	4000 (**)	90	70

* Sealed bearings: it is not necessary any maintenance during their entire operating life; in normal working conditions the estimated life is about 30,000 hours.
** In normal working conditions the regreaseble bearings have an estimated life of about 40,000 hours.

For possible replacement, follow the instructions given in paragraph 9.5.3.

It is mandatory to verify, for all machines equipped with a grease nipple, that the required lubrication intervals are respected. In fact, re-greasable bearings need to work ONLY if suitably lubricated.

9.4.2 Winding state and diode bridge fastening check

Type of intervention	Operator	Periodicity
		 Every 8000 hours / 1 year
PPE to wear		Materials and equipments
  		Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

Remove the back grid of the alternator for visual inspection of the windings and to check the fastening of the diode bridge.
If the windings are dirty or oily clean them with pressurized air.
In case problems of other kind are detected you must disassemble the alternator to solve them.

9.4.3 Copy of the alarms of the digital regulator

Type of intervention	Operator	Periodicity
		 Every 8000 hours / 1 year
PPE to wear		Materials and equipments
 		Personal Computer + interface + dedicated software.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

Mecc Alte's digital regulator are equipped with a special connector that allows you to download the data related to the recorded alarms.
Download this data to check the potential presence of anomalies and, if any, solve them.


Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.4.4 Check correct fastening of PMG (optional component)

Type of intervention	Operator	Periodicity
		 Every 8000 hours / 1 year
PPE to wear		**Materials and equipments**
		Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.



man_ECO_001-r00

You can add the PMG accessory to the ECO series alternators manufactured by Mecc Alte.

In case this accessory is present, make sure it is correctly attached.

See par. 9.5.6

9.4.5 Cleaning of windings

Type of intervention	Operator	Periodicity
		Every 20000 to 25000 hours.
PPE to wear		Materials and equipments
		Cleaning tools

Danger


Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

Caution

If the system operates in a dusty environment, the cleaning operations must be carried out more frequently.

Cleaning must be carried out using adequate products.

ECO 43 - 46



lay_ECO_001-r01

Disassemble the alternator for general cleaning.

In such case it is advisable to replace the bearings for an optimization of the maintenance interventions for the entire group.

The windings must be cleaned using a low pressure jet of hot water at a temperature below 80 °C or using adequate highly-evaporable solvents suitable for the cleaning of electrical windings.

These solvents allow an adequate cleaning without damaging the insulation of the windings.

When the cleaning is finished it is advisable to check if there are any signs of overheating and potential traces of carbonizations.
After the drying process at approximately 60-80°C is finished you must check again the insulation resistance of the windings.
In case you notice a degradation of the winding paint, paint them again.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.5 Maintenance in case of failure

9.5.1 Fan replacement assembling

Type of intervention	Operator	Periodicity
		

PPE to wear	Materials and equipments
	Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

Fan for ECO 43 - 46

The ECO 43-46 Series alternators use aluminum fans with a cast iron internal sleeve.
Assembling is carried out by heating the fan to 200 °C for 1 hour and then inserting it into the shaft.
A special extractor is used to remove it.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.5.2 Check and possible replacement of diode bridge


Type of intervention	Operator	Periodicity
		

PPE to wear	Materials and equipments
	Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

ECO 43 - 46



lay_ECO_001-r01

The diode bridge is made of a single circular block with six diodes (T18).
The configuration (T18) is used in the 43-46 Series alternators.
Every diode may be checked very easily with a multimeter set for diode verification; it is enough to completely disconnect the diode bridge under examination and to check every diode in both directions.
Once the sector or the entire bridge is replaced, tighten the corresponding screws with the correct tightening torques (see paragraph 9.6), and respecting the polarity.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.5.3 Mechanical disassembly for inspection (series 43-46)

Type of intervention	Operator	Periodicity
		

PPE to wear	Materials and equipments
	Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

Summary Disassembly Procedure.

Front Cover	To remove the front cover gently tap with a rubber mallet.
Rotor	The rotor is extracted from the back cover using an appropriate extractor. Once the bearing has come out of its housing, the rotor may be extracted, tying it with soft ropes for movement. During this operation you must be very careful not to damage the rotor windings.
Back cover	Before removing the back cover, disconnect the yellow-blue cables of the exciter stator from the regulator and free them of any fastening straps. During the removal of the back cover pull out the exciter stator cables as well. Pull the cables out gently so as to prevent them from getting stuck and damaged.
General Inspection	Examine every component (windings: exciter, auxiliary winding, stator and rotor) to check the presence of damages. Carefully check whether the crimp connectors are damaged.
Stator/Frame Inspection	• Carry out a visual inspection of the stator and of the frame. • Remove all dirt and dust. • Repair all potential damages to the windings. • Inspect the cable terminals and make sure they comply with the applicable regulations.
Shaft Inspection	Examine the shaft and the housings for the keys to check the presence of any sign of corrosion, burrs or wear. Clean them and, if necessary polish them. If the degree of wear of the shaft is too high, take it to a service center for repair or replacement.

Front/Back bearing disassembling

- Both bearings must be removed using the appropriate extractors.
- The sizes of the bearings must be measured accurately to check the presence of excessive wear.
- In case of excessive wear or anomalous noises / vibrations, replace them.

Electrical Inspections

Check the cable terminals and make sure they guarantee good contact. Make sure there are no signs of corrosion and/or oxidation.

Check whether the cable sheath is undamaged. If there are damage signs, repair or replace the cable.

Using adequate tools, check the resistance, the continuity and the insulation of the following windings (see paragraph 9.5.14):

- Main Stator.
- Auxiliary Winding.
- Main rotor.
- Exciter Stator.
- Exciter Rotor.
- Thermal probes (if present).
- PMG (if present).

Check whether the diodes and the varistor are damaged.

All the measurement tools must be calibrated.

Insulation checks

Check the insulation resistance of the following windings:

Main Stator:	• Between phases and between phases and ground. • Between phases and the auxiliary winding. • Between auxiliary winding and ground.
Main rotor and exciter rotor:	• Between winding and ground.
Exciter Stator:	• Between winding and ground.
PMG (if present):	• Between winding and ground.

The AVR may be controlled on a static bench or during the operating test of the machine

See paragraph 9.5.10; 9.5.11; 9.5.12; 9.5.13.

The internal windings of the machine might need accurate cleaning. Use an appropriate solvent or hot water. Dry them and, if necessary, impregnate them again.

Detailed disassembling procedure




Remove the cover of the terminal box and the pertaining panels, disconnect the digital regulator then remove the back latch and the back carter.

Cut the regulator cable fastening straps then pull the yellow and blue wires of the exciter stator through the cable gland hole.

Secure the exciter stator to an appropriate lifting device using a soft belt.


Remove the fixing screws and , using a lever, extract the exciter stator, being careful not to damage the windings.



Memorize the position of the wires so as to be able to reconnect them in the original position at the end of the intervention.

Disconnect the wires (A) connected to the rotating diode bridge (three wires from the exciter rotor and two wires from the main rotor).

Unscrew the three M5 screws (B) and remove the rotating diode bridge.




Unscrew the three M8 screws and remove the blocking hub of the exciter rotor.

Use a felt pen to mark on the exciter rotor the position of the key on the shaft.



Secure the exciter stator to an appropriate lifting device using a soft belt.

Remove it with the appropriate Mecc Alte extractor.



Cut the fastening strap of the cables of the main rotor on the shaft.



Use a felt pen to mark the position of the front and back cover with respect to the frame to allow their correct reassembling.

Remove the cover tightening bolts.



Hook the front cover to a lifting device.

Tap with a rubber mallet to remove it from the frame.



Hook the back cover to a lifting device.


Use an extractor to push the shaft until the bearing comes out completely from its housing.




Pass a soft belt on the shaft end and slightly lift the rotor.
Start pushing it to extract it.



As soon as possible, place the shaft end on an adequate support.
Move the soft rope onto the rotor pack and start extracting it.



As soon as the rotor sticks out enough, support it with a second soft belt.
Remove it from the frame and put it in a safe place.




Use an extractor to remove the bearing.

9.5.3.1 Note for removal of ECO 43 - 46 alternators



Before disassembling the back cover remove the four fixing bolts of the bridle.
On the 43 Series there is an additional grease protection ring. Be extremely careful when reassembling to center it well.



When disassembling it the lubricator tube for the bearing must be removed before removing the back carter.
When reassembling it, the lubricator tube is mounted right after the back carter is attached.

9.5.4 Mechanical assembly (series 43 - 46)

Reassembling bearings	Heat the bearings in an appropriate induction equipment. Insert them into the shaft by pushing them to the end stop against the shoulder. The heating temperature must not exceed the limit imposed by the manufacturer.
Rotor	Reassemble the rotor being very careful not to damage the windings.
Front Cover	To remove the front cover gently tap with a rubber hammer.
Back cover	During the assembling check the voltage of the exciter stator wires to avoid damaging them.
Fixing rod/bolts	To assemble the fixing rods and bolts use new washers and tighten them with the correct tightening torque. In case of double-bearing alternators, once assembled, turn them manually to check whether there are impediments and anomalous noises. In case of single-bearing alternators, this check must be carried out during the test, after the coupling with the drive motor.

Assembling Procedure




Caution
Use anti-burn gloves.


3) Once the rotor is in place, also seat the front cover on the housing, aligning the front bearing with its seat in the cover.

See paragraph 9.4.1.

Insert the new bearing on the shaft, push it to the end stop.
Wait for the bearing to cool off. Then start reassembling the alternator.



Lift the rotor using two soft belts.
Introduce the rotor in the frame.



As soon as possible, remove one of the soft belts and continue inserting the rotor.

Keep an adequate support under the shaft end.




Using an appropriate lifting system, lift the back cover and put it in position.

Screw a threaded bar in the hole on the shaft.

Screw a nut on the threaded bar. Insert a cylindrical spacer, overlapped by an adequate plate, between the nut and the back cover.

Screw the nut in to introduce the bearing in the housing of the back cover.



Lift the front cover and put it in position. Make sure you line up the (felt pen) marks made earlier on the covers and the frame.

Fasten the bolts (for 43 - 46 Series) to the tightening torques. (See paragraph 9.6).



Fasten the cables of the main rotor to the shaft with a strap.



Using an appropriate lifting system and a soft belt, lift the exciter rotor.

Introduce the rotor into the shaft, in its original position. Carefully observe the position of the key marked during the assembling stage.




Screw the six M8 screws to 25Nm to fasten the blocking hub of the exciter rotor.



Insert the rotating diode bridge and screw in the 3 M5 screws to 3.3 Nm.

Rewire the three cables of the exciter rotor and the two cables of the main rotor in their initial configuration.



Using a soft belt lift the exciter stator.

Introduce the exciter stator in the housing with the cables positioned inward and oriented upward.

Insert the fixing bolts and screw them with a torque of 25 Nm.

Pass the yellow and blue cables of the exciter stator through the cable gland hole on the frame.

Connect them to the regulator and fasten them with appropriate straps as in the original configuration.

Reassemble the back carter, the back cover and the terminal box.


9.5.5 PMG disassembling

Type of intervention	Operator	Periodicity
		


PPE to wear	Materials and equipments
	Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.



A. Remove the protective cover and grid.
B. Re-introduce the paper spacer.



C. Loosen the central M14 rod and, without removing it completely, use as a lever on the PMG device to uncouple it from the exciter rotor.

Secure the PMG to an appropriate lifting device using a soft belt.

D. Remove the 4 M8 screws .

Use a lever to remove the PMG device from the exciter stator, being careful not to remove the exciter stator too.

9.5.6 PMG assembly (series 43–46)

Type of intervention	Operator	Periodicity
		

PPE to wear




Materials and equipments


Workshop tools.

Danger


Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.




A. Remove the IP 23 back protective cover.
B. Remove the 6 M8 screws of the exciter stator.



C. Accurately clean the area indicated in the drawing of the exciter stator (1) and remove the paint from the PMG device (2).
Place the PMG close to the exciter stator paying attention to the correct positioning of the reference for ECO43-46 (4) and center the flange, screw the 6 M8 screws supplied applying a torque of 25 Nm.



E. Center the washer for the central rod in the rotor pack and screw in the central M14 rod applying a 120 Nm torque.
F. Remove the paper spacer.
G. Make sure the PMG is perfectly placed in the housing by checking that the rotating part rotates freely without any interference, then pass the wires as shown in the figure and connect them to the regulator according to the diagram.



H. Insert the special IP23 back grid and screw in the 12 screws applying a 12 Nm torque.

I. Insert the IP 23 protective cover and screw in the 2 screws at 3.5 Nm and insert the cap nut.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized


9.5.7 Removal of disc holder hub

Type of intervention	Operator	Periodicity
		

PPE to wear	Materials and equipments
	Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.



Use an appropriate hydraulic extractor to extract the hub.
For the 43 and 46 series use an additional flange attached to the hub.



Heat the disc holder hub. Use two oxyacetylene heating torches.
Keep the extractor under pressure until full extraction of the hub.

Before reassembling the hub heat it to 250 °C for 1 hour.


9.5.8 Loss of residual magnetism (re-excitation of the machine)

Type of intervention	Operator	Periodicity
		
PPE to wear		**Materials and equipments**
		Battery, electrical wires and resistance.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

The following procedure applies to the alternators equipped with an electronic regulator and must be applied in case the alternator does not self-excite (in such case, even if rotating at nominal speed, voltage is not present in the main terminal block of the alternator):



- With the alternator off, remove the cover of the terminal box.
- Prepare two terminals connected to a 12 Vdc battery possibly with a 5 Ω resistance in series.
- Use the electrical diagrams provided by Mecc Alte to identify the “+” and “-“ terminals of the electronic regulator.
- Start the alternator.
- Apply the two terminals to the previously identified terminals for a moment, taking great care to respect the polarities (the “+” terminal of the regulator with the “+” terminal of the battery, the “-” terminal of the regulator with the “-” terminal of the battery).
- Use a voltmeter or the corresponding board tools to check whether the alternator generates the nominal voltage indicated on the "nameplate" of the alternator.

9.5.9 Check and replacement of voltage regulator

Type of intervention	Operator	Periodicity
		
PPE to wear		**Materials and equipments**
  		Workshop tools.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.

The alternators are equipped with an automated voltage regulator: depending on the alternator type, the electronic regulators may be of 4 types: DSR, DSR/A, DER1, DER1/A.

In case there are voltage regulation problems not ascribable to an erroneous adjustment of the VOLT, STAB, Hz and AMP potentiometers and/or to the system (fully assembled machine + load), follow the procedure below for an in-depth check of the voltage regulator.

Visual Inspection of the Regulator

Do not change the position of the VOLT, STAB, Hz and AMP potentiometers before marking their position.

In particular check for:

- Mechanical damages of various kinds.
- State of fuses.
- Undamaged state of electrical connections.
- Potential presence of burned electrical components.
- Presence of the silicone protection in the Hz and AMP potentiometers.

Check the SCR resistance and flyback diode.

Before doing this test, check that the fuse is inserted and undamaged.

- Flyback diode: it is working if the diode test performed between pin 1 and 2 has a positive result.
- SCR: it is working if a resistance of some hundred KΩ is measured between pin 1 and 8 (in the DSR) or between pin 1 and 2 (in the DER1 regulator).

A resistance measure close to zero signals a SCR failure.


A reason for the damaging of these components may be the erroneous cabling of the alternator regulator.

Copy the data and alarms of the regulator.

To avoid creating new alarms, the copy of the data and alarms existing in the regulator (.dat and .alr files) must be made feeding the alternator with an appropriate continuous voltage, in accordance with the diagrams below.

The correct supply and operation of the software are signaled by a green LED flashing with a 1 second period. If the LED is not lit try to turn the power supply system off and restart it.

Testing on static bench (see paragraph 9.5.11, 9.5.12, and 9.5.13)




- Register the position of the VOLT, STAB, Hz and AMP potentiometers reading the L[32], L[33], L[34] and L [35] corresponding parameters and the state parameters, reading L[36], L[37], L[38] and L[39].
- Check the correct operation of the VOLT, STAB, Hz and AMP potentiometers, rotate them completely in anticlockwise and clockwise direction, the value of the L[32], L[33], L[34] and L[35] parameters must be 64 in one direction and 32760 in the other direction.
- Register the L[41] parameter; with the external potentiometer unconnected you should read a value of 16384; otherwise the external potentiometer circuit is damaged.
- Voltage regulation test: set the VOLT, STAB and Hz potentiometers to notch 6 then rotate the AMP potentiometer completely in clockwise direction. Read the L[43] and L[44] parameters.

When rotating the VOLT potentiometer in anticlockwise or in clockwise direction, the value of the L[43] parameter should respectively decrease or increase.
Check and confirm the following behavior: if the L[43] value is higher than the L[44] value, the bench light bulb should brighten.
If instead the L[43] value is lower than the L[44] value, the light bulb should dim until it shuts off.
The light bulb represents the fictitious load connected between connectors 1 and 2 of the digital regulator.

- AMP protection test: set the STAB and Hz potentiometers to notch 6, then rotate the AMP potentiometer completely in clockwise direction; then rotate the VOLT potentiometer so as to have L[43] higher than L[44], the bench light bulb on and no active alarm.


Read the L[45] parameter and set the AMP potentiometer (reading the L[35] parameter for the SN equipped regulators with a yellow tag, or L[55] for the SN-equipped regulators with a blue tag, to a lower value than the value of the previously read L[45] parameter. Check the intervention of the AMP protection (alarm 5).

Once you established that the regulator must be replaced, proceed as follows:



ins_ECO_004-r00

- Disconnect all the connection wires in the terminal block.
- Unscrew the blocking 2/4 screws of the regulator.



ins_ECO_005-r00

- Place the new regulator in the specified position.
- Fasten the new regulator with the previously collected screws.
- Reconnect all the wires to the terminal block of the regulator, using, if necessary, the diagrams provided by Mecc Alte.

In case you detect anomalous behavior please refer to the specific regulator manual or contact Mecc Alte's technical support service

9.5.10 DSR test and setup on test bench

Type of intervention	Operator	Periodicity
		
PPE to wear		**Materials and equipments**
  		Personal computer+interface+software.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies. Disconnect the regulator and connect to a computer according to the diagrams below. The operations of functional checkout and parameter setting may be easier if they are performed on a test bench rather than with the regulator still inside the terminal box.


Caution

Given that some parts of the DSR which work with a high potential are not isolated, for the safety of the operator, it is necessary for the power source to be isolated from the electrical grid, for instance by a transformer.

Caution

The use of these types of connection is reserved to qualified personnel, able to assess the operational risks of high voltage and who have a full knowledge of the content of this manual.


The connection diagrams of the DSR and the USB2DxR communication interface are shown in figures (A), (B) or (C) in this paragraph based on the requested function and on the available supply voltage.



DSR 48Vdc power supply for the download of the alarms without risking to change to content of the EEPROM because of the tests.

No other connections besides the power supply are needed.


B



DSR 70-140Vac power supply for test and setup.

The fictitious load between terminals 1 and 2, the sensing on terminal 7 and the bridge between terminals 6 and 3 of the DSR.

C



DSR 140-270Vac power supply for testing and setup.

The fictitious load between terminals 1 and 2, the sensing on terminal 5 and the bridge between terminals 3 and 4 of the DSR.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.5.11 DER1 test and setup on test bench

Type of intervention	Operator	Periodicity
		
PPE to wear		**Materials and equipments**
		Personal computer+interface+software.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies. Disconnect the regulator and connect to a computer according to the diagrams below. The operations of functional checkout and parameter setting may be easier if they are performed on a test bench rather than with the regulator still inside the terminal box.

Caution


Given that some parts of the DER1 which work with a high potential are not isolated, for the safety of the operator, it is necessary for the power source to be isolated from the electrical grid, for instance by a transformer.

Caution

The use of these types of connection is reserved to qualified personnel, able to assess the operational risks of high voltage and who have a full knowledge of the content of this manual.

The connection diagrams of the DER1 and the USB2DxR communication interface are shown in figures (A), (B) or (C) in this paragraph based on the type of available power supplies.


A



DER1 48Vdc power supply for the download of the alarms without risking to change to content of the EEPROM because of the tests.

No other connections besides the power supply are needed.


B



DER1 75-150Vac power supply for test and setup.

The fictitious load between terminals 1 and 2, the sensing on terminal 6 and the bridge between terminals 8 and 9, 7 and 15, 12 and 16, 19 and 22.

C



DER1 150-150Vac power supply for test and setup.

The fictitious load between terminals 1 and 2, the sensing on terminal 4 and the bridge between terminals 5 and 14, 12 and 17, 19 and 22.

9.5.12 DER 2 test and setup on test bench

Type of intervention	Operator	Periodicity
		
PPE to wear		**Materials and equipments**
		Personal computer+software.

Danger

Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies. Disconnect the regulator and connect to a computer according to the diagrams below. The operations of functional checkout and parameter setting may be easier if they are performed on a test bench rather than with the regulator still inside the terminal box.


Caution

Given that some parts of the DSR which work with a high potential are not isolated, for the safety of the operator, it is necessary for the power source to be isolated from the electrical grid, for instance by a transformer.

Caution

The use of these types of connection is reserved to qualified personnel, able to assess the operational risks of high voltage and who have a full knowledge of the content of this manual.


The connection diagrams of the DER2 are shown in figures (A), (B) or (C) in this paragraph based on the type of available power supplies.



DER1 48Vdc power supply for the download of the alarms without risking to change to content of the EEPROM because of the tests.

No other connections besides the power supply are needed.


B



DER2 75-150Vac power supply for test and setup.

The fictitious load between terminals 1 and 2, the sensing on terminal 6 and the bridge between terminals 8 and 9, 7 and 15, 12 and 16, 19 and 22.

C



DER2 150-270Vac power supply for test and setup.


The fictitious load between terminals 1 and 2, the sensing on terminal 4 and the bridge between terminals 5 and 14, 12 and 17, 19 and 22.

9.5.13 Main stator windings voltage test

Type of intervention	Operator	Periodicity
		
PPE to wear		**Materials and equipments**
		Electrical tools.

Danger


Disconnect the alternator from the power supplies. The drive motor must be off and unplugged from its power supplies.



Use a multimeter to check all three phases (both L-L and L-N).
When off-load the voltage should be balanced on all three phases with a ± 1% tolerance.
If the voltage is unbalanced, this indicates a problem in the main winding of the stator.
If instead the voltage is balanced on the three phases, then the winding of the stator does not have problems.
If the voltage is lower than 15% of the nominal voltage, there might be a problem with the regulator, in the rotating diode bridge or in the exciter winding.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.5.13.1 Resistance/Continuity Test




Main Stator

Use an appropriate tool to measure the phase resistance/continuity 1-2, 3-4, 5-6, 7-8, 9-10 and 11-12

Also check the resistance/continuity of the auxiliary winding between the two red wires coming out of the main stator.


For the values see paragraph 2.3.



Main rotor

Measure the resistance/continuity of the main rotor using a multimeter.

For the values see paragraph 2.3.



Exciter stator

Measure the resistance/continuity of the winding of the exciter stator between the positive wire (yellow) and the negative one (blue) with a multimeter.

For the values see paragraph 2.3.




Exciter rotor

Measure the resistance/continuity of the winding of the exciter rotor between phases with a multimeter.

For the values see paragraph 2.3.

9.5.13.2 Insulation test



Main Stator

Completely disconnect the AVR and the connection between neutral and ground before performing this test.


The measurement must be carried out using an insulation tester (Megger) of 500 V.

Check the insulation between phases, between phases and ground, between auxiliary and phases and between auxiliary and ground.

For these alternators, the minimum insulation value is of 5MΩ.

If the insulation resistance is lower, the stator must be cleaned and, if necessary, impregnated or painted again with EG43 gray paint and then dried at 50-60 °C.

If after these operations the value remains low, the stator must be rewound or replaced.




Main rotor

The insulation resistance is measured between phase and ground using an insulation tester (Megger).

For these alternators, the minimum insulation value is of 5MΩ.

If the insulation resistance is lower, the rotor must be cleaned and, if necessary, impregnated and then dried at 50-60 °C.

If after these operations the value remains low, the rotor must be rewound or replaced.



Exciter stator

The insulation resistance is measured between phase and ground using an insulation tester (Megger).

For these alternators, the minimum insulation value is of 5MΩ.

If the insulation resistance is lower, the stator must be cleaned and, if necessary, painted again with EG43 gray paint and then dried at 50-60 °C.

If after these operations the value remains low, then the stator must be rewound or replaced.



Exciter rotor

The insulation resistance is measured between phase and ground using an insulation tester (Megger).

For these alternators, the minimum insulation value is of 5MΩ.

If the insulation resistance is lower, the rotor must be cleaned and, if necessary, impregnated and then dried at 50-60 °C.

If after these operations the value remains low, the rotor must be rewound or replaced.

9.6 General tightening torques

9.6.1 ECO43 Series

43 Series				
Application	**Screw type**		**[Nm] ± 7% Tightening Torque**	**Replacement parts cat. reference**
Fastening of 80mm exciter stator	M8 X 100	CL. 8.8	25	10
Front Cover	M14 X 50	CL. 8.8	120 ± 10%	9
Back cover	M14 X 70	CL. 8.8	120 ± 10%	7
terminal box	M6 X 16	CL. 8.8	12	2, 95, 96, 97
Fastening the terminal block to the frame	M6 X 25	CL. 8.8	9	
IP2X protection of front cover	M5 X 25	CL. 4.8	3.3	39
Fastening terminals to bearing	M6 X 45	CL. 10.9	9	140
Fastening of cable terminals	M10 X 40	CL. 8.8	48	
Fastening bridge to terminals (phase L1, L2, L3)	M10 X 50	CL. 8.8	48	141
Fastening bridge to terminals (star point)	M10 X 60	CL. 8.8	48	141
3-plate terminal block support bracket	M6 X 25	CL. 8.8	9	139
Terminal board support bracket	M8 X 40	CL. 8.8	12	139
Back grease protection ring	M12 X 85	CL. 8.8	100 ± 10%	
Front grease protection ring	M6 X 80	CL. 8.8	9	
Back V-shaped closure	M6 X 16	CL. 8.8	9	94
Fastening of exciter rotor	M8 X 35	CL. 8.8	21	13
Fastening of balancing ring	M8 X 20	CL. 8.8	21	
Back cover ground wire	M16 X 30	CL. 8.8	180 ± 10%	7
Rotor bracket	M10 X 75	CL. 8.8	35	14
Regulator	M4 X 25	CL. 4.8	1	23
Fastening of paralleling device	M4 X 16	CL. 4.8	1	
Terminal block for paralleling device	M3 X 25	CL. 4.8	0.3	
Rotating diode bridge	M5 X 25	CL. 4.8	3.3	11
	M5 X 20	Brass	3.3	11
	M5 X 25	Brass	3.3	11

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

43 Series				
Application	**Screw type**		**[Nm] ± 7% Tightening Torque**	**Replacement parts cat. reference**
Flywheel				
Flywheel 14	M16 X 55	CL. 8.8	200 ± 10%	60
Flywheel 18	M16 X 40	CL. 8.8	200 ± 10%	60
Flywheel 21	M16 X 40	CL. 8.8	200 ± 10%	60
Optional				
Terminal block for accessories	M3 X 25	CL. 4.8	0..5	
Front IP45 air filter	M5 X 16	CL. 4.8	3.3	
Back IP45 air filter	M6 X 16	CL. 8.8	9	
PMG	M5 X 10	CL. 4.8	3.3	
	M6 X 80	CL. 4.8	9	
	M8 X 100	CL. 8.8	25	
	M14 X 227		120 ± 10%	
Terminal block bridge for transformer	M10 X 40	CL. 8.8	48	
	M10 X 50	CL. 8.8	48	
	M10 X 60	CL. 8.8	48	
	M5 X 20	CL. 4.8	2	
	M6 X 30	CL. 8.8	9	

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.6.2 ECO46 Series

46 Series				
Application	**Screw type**		**[Nm] ± 7% Tightening Torque**	**Replacement parts cat. reference**
Fastening of 120mm exciter stator	M8 X 140	CL. 8.8	25	10
Front Cover	M14 X 70	CL. 8.8	120 ± 10%	9
Back cover	M14 X 70	CL. 8.8	120 ± 10%	7
terminal box	M6 X 16	CL. 8.8	12	2, 95, 96, 97
Fastening the terminal block to the frame	M6 X 25	CL. 8.8	9	
IP2X protection of front cover	M5 X 25	CL. 4.8	3.3	39
Fastening terminals to bearing	M6 X 45	CL. 10.9	9	140
Fastening of cable terminals	M10 X 40	CL. 8.8	48	
Fastening bridge to terminals (phase L1, L2, L3)	M10 X 50	CL. 8.8	48	141
Fastening bridge to terminals (star point)	M10 X 70	CL. 8.8	48	141
3-plate terminal block support bracket	M8 X 40	CL. 8.8	12	142
Terminal board support bracket	M8 X 35	CL. 8.8	12	142
Back grease protection ring	M6 X 85	CL. 8.8	9	
Front grease protection ring	M6 X 100	CL. 8.8	9	
Back V-shaped closure	M6 X 16	CL. 8.8	9	94
Fastening of exciter rotor	M8 X 35	CL. 8.8	21	13
Fastening of balancing ring	M8 X 20	CL. 8.8	21	
Back cover ground wire	M16 X 30	CL. 8.8	180 ± 10%	7
Rotor bracket (only 4 poles)	M10 X 80	CL. 8.8	43	14
Rotor bracket (only 6 poles)	M10 X 110	CL. 8.8	43	14
Regulator	M4 X 25	CL. 4.8	1	23
Fastening of paralleling device	M4 X 16	CL. 4.8	1	
Terminal block for paralleling device	M3 X 25	CL. 4.8	0.5	
Rotating diode bridge	M5 X 25	CL. 4.8	3.3	11
	M5 X 20	Brass	3.3	11
	M5 X 25	Brass	3.3	11

46 Series				
Application	**Screw type**		**[Nm] ± 7% Tightening Torque**	**Replacement parts cat. reference**
Flywheel				
Flywheel 18	M16 X 40	CL. 8.8	200 ± 10%	60
Flywheel 21	M16 X 40	CL. 8.8	200 ± 10%	60
Optional				
Terminal block for accessories	M3 X 25	CL. 4.8	0..5	
Front IP45 air filter	M6 X 20	CL. 8.8	9	
Back IP45 air filter	M6 X 16	CL. 8.8	9	
PMG	M5 X 10	CL. 4.8	3.3	
	M6 X 80	CL. 4.8	9	
	M8 X 150	CL. 8.8	25	
	M14 X 267		120 ± 10%	
Terminal block bridge for transformer	M10 X 40	CL. 8.8	48	
	M10 X 50	CL. 8.8	48	
	M10 X 70	CL. 8.8	48	
	M5 X 20	CL. 4.8	2	
	M6 X 30	CL. 8.8	9	


Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

9.7 Disc tightening torques

In case of replacement of discs, the appropriate tightening torques are indicated here (fastening discs to hub).

Type	SAE	L	Screw size		Tightening Torques (Nm)	
			TE	TCCEI	CL. 8.8	CL. 12.9
ECO43	14	25,4	M16x55-8.8	/	200 ± 10%	/
	18	15,7	M16x40-8.8	/	200 ± 10%	/
	21	0	M16x40-8.8	/	200 ± 10%	/
ECO46	18	15,7	M16x40-8.8	/	200 ± 10%	/
	21	0	M16x40-8.8	/	200 ± 10%	/

9.8 Terminal block tightening torques



THREAD DIAMETER Df	TYPE	TIGHTENING TORQUE (Nm)
M10 (Steel)	ECO43 ECO46	48 ± 7%


Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

10 Alarm management DSR / DER1

The state of the active alarms is visualized at location 38 that may be read through USB.
The index of the bits that present value 1 correspond to an active alarm.
If the regulator is working regularly (no active alarm) the B11 bit will result active.

No.	Event description	Action
1	EEprom Checksum	Restoring default data, Block
2	Overvoltage	APO
3	Undervoltage	APO
4	Short circuit	APO, Maximum current, Block
5	Excitation Overcurrent	APO, Reduction of Excitation Current
6	Low speed	APO, V/F Ramp
7	Overspeed	APO
8	Underexcitation /loss of excitation	APO

During normal operation a LED indicator mounted on the card flashes with a 2 second period and 50% duty cycle.
In case of intervention or signaling of any alarm there are different flashing modes available, as shown in the figure below.



dis_ECO_012-r00

10.1 DSR/DER1 digital regulator alarms

ALARM DESCRIPTION		
No.	**Event description**	**Action**
1	Erroneous EEPROM control code	It is checked on start (after the DSP reset and the launch of the peripheral devices). The actions taken are: signaling, loading default settings, saving in EEPROM and blocking the regulator. Upon restart, if EEPROM is faulty, the alarm will be repeated, otherwise the regulator will start to operate on default parameters.
2	Overvoltage	Overvoltage is calculated using an appropriate window, based on the speed and it is inhibited during the transients, for 2 sec. The alarm does not determine a change in the LED flash, enables APO output and is memorized. It may be caused either by anomalous operating conditions (such as overspeed or capacitive load) or by any fault in the regulator. The overvoltage alarm is activated only if the angle has already been reduced to zero and, therefore, output voltage control has been lost. In the calculation window the threshold is set to 5% above the nominal value.
3	Undervoltage (@ ωN)	The alarm does not determine a change in the LED flash, enables APO output and is memorized. Undervoltage is calculated using an appropriate window based on the speed (visible in the undervoltage alarm description), the threshold is set to 5% under the nominal value; it intervenes only above the intervention threshold of the low speed alarm, it basically is inhibited by it. It is also inhibited in case of intervention of the "excitation overcurrent" alarm and during transients.
4	Short circuit	The alarm is disabled under 20Hz and visualized and memorized when action is activated. Tolerated short circuit time goes from 0.1 to 25,5 seconds (programmable in 100ms steps); then the regulator, after having saved DD and TT, turns to block mode and signals the STOP status. With the "short circuit time" parameter set to zero, the block is disabled. The reduction of the angle may cause an excitation drop, with a consequent stop and subsequent restart of the regulator and then the cycle is repeated.
5	Excitation Overcurrent	This alarm's function is not only to signal a state of excess accumulation of heating of the exciter, but also an active function of elimination of the cause. There is in fact a regulation ring that takes over after a threshold is exceeded; the action determines the reduction of the excitation current and then of the output voltage. The available parameter is the "threshold", which determines, in the end, the balance value at which the system stabilizes. The alarm is signaled and memorized. For the adjustment see paragraph "Excitation overcurrent".
6	Low speed	This alarm also appears at start and at stop. Under the threshold the V/F ramp is present. The alarm does not trigger data saving in EEPROM. The alarm intervention threshold depends on the 50/60 jumper status (hardware or software) and on the Hz trimmer position or on the value of parameter 21. (Immediate) Signaling and activation of the V/F ramp.

ALARM DESCRIPTION		
No.	**Event description**	**Action**
7	Overspeed	The threshold may be set through parameter 26. It is visualized similarly to the low speed alarm, it does not trigger actions on control and it is memorized. The overspeed condition may cause, as in the case of capacitive load, an overvoltage.
8	Underexcitation / Loss of excitation	The alarm is inhibited during transients. The alarm does not determine a change in the LED flash, enables APO output and is memorized. The alarm condition is recognized by a underexcitation / loss of excitation observer, available for reading at location L[56]: if the value of L[56] is higher than the upper (fixed) threshold or lower than the value of the lower threshold (parameter P[27]), A-08 is activated.

11 Problems, causes and remedies

The alternator does not excite.	Faulty fuse.	Check the fuse and if necessary replace it.
	Faulty diodes.	Check the diodes and if necessary replace them (see paragraph 9.5.2).
	Speed too low (lower than nominal speed).	Adjust the speed to the nominal value.
	Residual magnetism too low.	Adjust the speed to the nominal value.
The alternator de-excites after excited state.	Connection cables damaged or disconnected.	Check the state and correct fastening of cables. Check the correct connection of cables using the attached drawings.
At no load low voltage	Regulator is not adjusted.	Readjust the voltage and/or stability. (see paragraph 8.1.1 and 8.2.1).
	Faulty regulator.	Replace the regulator.
	Speed lower than nominal speed.	Check the number of rotations.
	Damaged windings.	Check windings. (see paragraph 9.5.14 and 9.5.6).
At no load voltage is too high.	Regulator is not adjusted.	Readjust the voltage and/or stability. (see paragraph 8.1.1 and 8.2.1).
	Faulty regulator.	Replace the regulator.
At load, voltage is lower than nominal voltage.	Regulator is not adjusted.	Readjust the voltage and/or stability. (see paragraph 8.1.1 and 8.2.1).
	Faulty regulator.	Replace the regulator.
	Current is too high, cos φ lower than 0.8, speed lower than 4% nominal speed.	Operating outside the standard parameter range. Adjust the alternator back to standard parameters.
	Faulty diodes.	Check the diodes and if necessary replace them (see paragraph 9.5.2).
At load, voltage is higher than nominal voltage.	Regulator is not adjusted.	Readjust the voltage and/or stability. (see paragraph 8.1.1 and 8.2.1).
	Regulator is not adjusted.	Replace the regulator.

Unstable voltage.	Instability of the drive motor rotation speed.	Check uniformity of the drive motor rotation speed.
	"STAB" potentiometer of the regulator not adjusted.	Adjust stability of the regulator by turning the "STAB" potentiometer. (see paragraph 8.1.1 and 8.2.1).
High bearing temperature.	Scarce or too much bearing lubrication.	Check amount of grease (see paragraph 9.4.1).
	Damaged bearing.	Replace the bearing (see paragraph 9.5.8).
	Shaft Misalignment.	Check alignment (see paragraph 5.3.2).
Temperature of cooling air is high.	Ambient temperature is high.	Check the ventilation in the room to ensure correct temperature.
	Air backflow towards the machine.	Check for presence of obstructions around the machine.
	Aspiration of obstructed area.	Check the air vents.
	Heat source nearby the air vents.	Move heat source or machine.
	Air filter is clogged.	Clean or replace the air filter (see paragraph 9.3.2).
Vibration	Damaged bearings.	Replace bearings (see paragraph 9.5.8).
	Unbalancing/break of cooling fan.	Check/replace cooling fan (see paragraph 9.5.1).
	Inefficient base-attachment system.	Check attachment system.
	Misalignment between alternator and drive motor.	Check alignment between alternator and drive motor (see paragraph 5.3.2).

For any other anomaly please contact the reseller, in the authorized service centers or directly at Mecc Alte.


12 Wiring diagrams

Regulator type	Connection	Drawing No.
DSR	12 terminals - single-phase reference	SCC0062
DSR	12 terminals - single-phase reference	SCC0063
DSR	12 terminals - single-phase reference	SCC0064
DER1/DER2	12 terminals - single-phase reference	SCC0161
DER1/DER2	12 terminals - single-phase reference	SCC0160
DER1/DER2	12 terminals - three-phase reference	SCC0159
DER1/DER2	12 terminals - three-phase reference	SCC0158
DER1/DER2	12 terminals - single-phase reference	SCC0202
DER1/DER2	12 terminals - ZIG-ZAG connection, single-phase reference	SCC0203
DER1/DER2	12 terminals - single-phase reference	SCC0236
DER1/DER2	12 terminals - single-phase reference	SCC0237
DSR	12 terminals - with PMG, single-phase reference	SCC0155
DER1/DER2	12 terminals - with PMG, single-phase reference	SCC0231
DER1/DER2	12 terminals - with PMG, single-phase reference	SCC0232
DER1/DER2	12 terminals - with PMG, three-phase reference	SCC0234
DER1/DER2	12 terminals - with PMG, three-phase reference	SCC0235
SR7	6 terminals - single-phase reference	A2544
UVR6	6 terminals - single-phase reference	A2550
SR7	12 terminals - single-phase reference	A2545
UVR6	12 terminals - single-phase reference	A2549
UVR6	6 terminals - three-phase reference	A2548
UVR6	12 terminals - three-phase reference	A2552
SR7	12 terminals - ZIG-ZAG connection, single-phase reference	SCC0055
UVR6	12 terminals - ZIG-ZAG connection, single-phase reference	SCC0054


Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

12.1 DSR digital regulator wiring diagrams


SCC0062: Alternators with 12 terminals with reference on half phase from 70 V to 140 V.



SCC0063: Alternators with 12 terminals for star or delta connections, reference on the entire phase from 140 V to 280 V.




SCC0064: Alternators with 12 terminals with reference on half phase from 140 V to 280 V.




12.2 DER 1 digital regulator electrical diagrams

SCC0161: Alternators with 12 terminals, 150 V - 300 V single-phase sensing.




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

SCC0160: Alternators with 12 terminals, single-phase reference from 75 V to 150 V.




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

SCC0159: Alternators with 12 terminals, three-phase reference from 150 V to 300 V.




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

SCC0158: Alternators with 12 terminals, three-phase reference from 75 V to 150 V.




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

SCC0202: Alternators with 12 terminals, single-phase reference from 300 V to 600 V.




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

SCC0203: Alternators with 12 terminals, ZIG-ZAG connection, single-phase reference from 300 V to 600 V.




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

SCC0236: Alternators with 12 terminals, single-phase reference from 150 V to 300 V



The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme


SCC0237: Alternators with 12 terminals, single-phase reference from 75 V to 150 V




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

12.3 Wiring diagrams with PMG

SCC0155: Alternators with 12 terminals, with PMG, DSR regulator. (Terminal 4: reference from 140V to 280V, terminal 6: reference from 70V to 140V).




SCC0231: Alternators with 12 terminals, with PMG, DER1 regulator, single-phase reference from 75V to 150V.



The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme


SCC0232: Alternators with 12 terminals, with PMG, DER1 regulator, single-phase reference from 150V to 300V.



The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme


SCC0234: Alternators with 12 terminals, with PMG, DER1 regulator, three-phase reference from 75V to 150V.

sch_SCC0234-01_001=00



The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme


SCC0235: Alternators with 12 terminals, with PMG, DER1 regulator, three-phase reference from 150V to 300V.




The electric scheme is valid also in case of use of the DER2 regulator instead of the DER1 regulator, represented in the scheme

12.4 Electrical diagrams with UVR6 - SR7 regulators


A2544: Alternators with 6 terminals, with SR7 analog regulator.




A2550: Alternators with 6 terminals, with UVR6 analog regulator.




A2545: Alternators with 12 terminals, with SR7 analog regulator.




A2549: Alternators with 12 terminals, with UVR6 analog regulator.




A2548: Alternators with 6 terminals, three-phase reference with UVR6 analog regulator.




A2552: Alternators with 12 terminals, three-phase reference with UVR6 analog regulator.



SCC0055: Alternators with 12 terminals (ZIG ZAG connection), with SR7 analog regulator.




SCC0054: Alternators with 12 terminals (ZIG ZAG connection), with UVR6 analog regulator.



13 Spare parts

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

13.1 ECO 43A Construction type MD35




ECO 43 List of replacement parts

Item	Name
1	Back latch
2	Protective cover
7	Back cover
8	Frame with stator
9	Front Cover
	MD35 SAE 0 MD35 SAE 00
10	Exciter stator
11	Rotating diode bridge
12	Exciter blocking hub
13	Exciter rotor
14	Rotating Inductor
15	Fan
17	Front bearing
18a	Internal front flange
18b	Internal back flange
19	Back bearing
23	DER1/A Electronic Regulator
39a	SIngle-bearing protective net
42	Fastening of paralleling device

Item	Name
59	Flywheel disc holder hub 21
	Flywheel disc holder hub 18
60	SAE 21 Discs
	SAE discs 18
75a	Cable gland rubber washer
75b	Cable gland rubber washer DG29
94	Back carter
95	Panel on terminal block side
96	Terminal block back panel
97	Terminal block back panel
98	Regulator holder panel
99	Disc blocking ring
138a	Back lubricator tube
139	Terminal board support bracket
140	Aluminum terminal
141a	Aluminum bridge
141b	Aluminum connection bar
142	Support bracket
178a	EPDM rubber profile size 8.5x5.5mm
178b	UL EPDM+SP reinforced profile size 15.6x8.4mm

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

13.2 ECO 43A Construction type B3B14



ECO 43 List of replacement parts

Item	Name
1	Back latch
2	Protective cover
7	Back cover
8	Frame with stator
9a	Front Cover B3B14
10	Exciter stator
11	Rotating diode bridge
12	Exciter blocking hub
13	Exciter rotor
14	Rotating Inductor
15	Fan
17	Front bearing
18a	Internal front flange
18b	Internal back flange
19	Back bearing
23	DER1/A Electronic Regulator
39a	SIngle-bearing protective net
39b	Double-bearing protective net

Item	Name
42	Fastening of paralleling device
75a	Cable gland rubber washer
75b	Cable gland rubber washer DG29
94	Back carter
95	Panel on terminal block side
96	Terminal block back panel
97	Terminal block back panel
98	Regulator holder panel
138a	Back lubricator tube
138b	Front lubricator tube B3B14
139	Terminal board support bracket
140	Aluminum terminal
141a	Aluminum bridge
141b	Aluminum connection bar
142	Support bracket
178a	EPDM rubber profile size 8.5x5.5mm
178b	UL EPDM+SP reinforced profile size 15.6x8.4mm

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

13.3 ECO 46A Construction type MD35




ECO 46 List of replacement parts

Item	Name
1	Back latch
2	Protective cover
7	Back cover
8	Frame with stator
9	Front Cover
	MD35 SAE 0 MD35 SAE 00
10	Exciter stator
11	Rotating diode bridge
12	Exciter blocking hub
13	Exciter rotor
14	Rotating Inductor
15	Fan
17	Front bearing
18a	Internal front flange
18b	Internal back flange
19	Back bearing
23	DER1/A Electronic Regulator
39a	SIngle-bearing protective net
39b	Double-bearing protective net
42	Fastening of paralleling device

Item	Name
59	Flywheel disc holder hub 21
	Flywheel disc holder hub 18
60	SAE 21 Discs
	SAE discs 18
75a	Cable gland rubber washer
75b	Cable gland rubber washer DG29
94	Back carter
95	Panel on terminal block side
96	Terminal block back panel
97	Terminal block back panel
98	Regulator holder panel
99	Disc blocking ring
138a	Back lubricator tube
139	Terminal board support bracket
140	Aluminum terminal
141a	Aluminum bridge
141b	Aluminum connection bar
142	Support bracket
178a	EPDM rubber profile size 8.5x5.5mm
178b	UL EPDM+SP reinforced profile size 15.6x8.4mm

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

13.4 ECO 46A Construction type B3B14



ECO 46 List of replacement parts

Item	Name
1	Back latch
2	Protective cover
7	Back cover
8	Frame with stator
9a	Front Cover B3B14
10	Exciter stator
11	Rotating diode bridge
12	Exciter blocking hub
13	Exciter rotor
14	Rotating Inductor
15	Fan
17	Front bearing
18a	Internal front flange
18b	Internal back flange
19	Back bearing
23	DER1/A Electronic Regulator
39b	Double-bearing protective net

Item	Name
42	Fastening of paralleling device
75a	Cable gland rubber washer
75b	Cable gland rubber washer DG29
94	Back carter
95	Panel on terminal block side
96	Terminal block back panel
97	Terminal block back panel
98	Regulator holder panel
138a	Back lubricator tube
138b	Front lubricator tube B3B14
139	Terminal board support bracket
140	Aluminum terminal
141a	Aluminum bridge
141b	Aluminum connection bar
142	Support bracket
178a	EPDM rubber profile size 8.5x5.5mm
178b	UL EPDM+SP reinforced profile size 15.6x8.4mm

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

14 Disassembly and disposal

To dispose of the alternator or its components you will have to recycle it, keeping in mind the nature of its various components (for instance: metals, plastic parts, rubber, oil and so on).
You will have to designate specialized companies for this purpose and , however, observe the waste management applicable laws.

Most of the materials used in the alternators can be recycled by specialized waste management companies. The instructions contained in this chapter are recommendations to follow for environmentally sound disposal; the user has the responsibility of observing local regulations.

For indicative percentages of the materials used in Mecc Alte alternators see paragraph 2.3.

Mecc Alte S.p.A. - Full or partial reproduction prohibited, if not authorized

Mecc Alte SpA (HQ)
Via Roma
20 - 36051 Creazzo
Vicenza - ITALY
T: +39 0444 396111
E: info@meccalte.it
aftersales@meccalte.it

Mecc Alte Portable
Via A. Volta
1 - 37038 Soave
Verona - ITALY
T: +39 045 6173411
E: info@meccalte.it

Mecc Alte Power Products srl
Via Melaro
2 - 36075 Montecchio
Maggiore (VI) - ITALY
T: +39 0444 1831295
E: info@meccalte.it

Zanardi Alternators
Via Dei Laghi
48/B - 36077 Altavilla
Vicenza - ITALY
T: +39 0444 370799
E: info@zanardialternatori.it

United Kingdom
Mecc Alte U.K. LTD
6 Lands' End Way
Oakham
Rutland LE15 6RF
T: +44 (0) 1572 771160
E: info@meccalte.co.uk

Spain
Mecc Alte España S.A.
C/ Rio Taibilla, 2
Polig. Ind. Los Valeros
03178 Benijofar (Alicante)
T: +34 (0) 96 6702152
E: info@meccalte.es

China
Mecc Alte Alternator Haimen LTD
755 Nanhai East Rd
Jiangsu HEDZ 226100 PRC
T: +86 (0) 513 82325758
E: info@meccalte.cn

India
Mecc Alte India PVT LTD
Plot NO: 1, Sanaswadi
Talegaon
Dhamdhere Road Taluka:
Shirur, District:
Pune - 412208
Maharashtra, India
T: +91 2137 619600
E: info@meccalte.in

U.S.A. and Canada
Mecc Alte Inc.
1229 Adams Drive
McHenry, IL. 60051
T: +1 815 344 0530
E: info@meccalte.us

Germany
Mecc Alte Generatoren GmbH
Bucher Hang 2
D-87448 Waltenhofen
T: +49 (0)831 540755 0
E: info@meccalte.de

Australia
Mecc Alte Alternators PTY LTD
10 Duncan Road, PO Box 1046
Dry Creek, 5094, South
Australia
T: +61 (0) 8 8349 8422
E: info@meccalte.com.au

France
Mecc Alte International S.A.
Z.E.La Gagnerie
16330 ST.Amant de Boixe
T: +33 (0) 545 397562
E: info@meccalte.fr

Far East
Mecc Alte (F.E.) PTE LTD
19 Kian Teck Drive
Singapore 628836
T: +65 62 657122
E: info@meccalte.com.sg

mecc alte

www.meccalte.com